

# HP StorageWorks

## Edge Switch 2/24 installation guide

FW 07.00.00/HAFM SW 08.06.00

**Legal and notice information**

© Copyright 2002–2005 Hewlett-Packard Development Company, L.P.

© Copyright 2002–2005 McDATA Corporation.

Hewlett-Packard Company makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

This document contains proprietary information, which is protected by copyright. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of Hewlett-Packard. The information is provided "as is" without warranty of any kind and is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Intel is a trademarks or registered trademark of Intel Corporation or its subsidiaries in the United States and other countries.

Java is a US trademark of Sun Microsystems, Inc.

Microsoft, Windows, and Windows NT are U.S. registered trademarks of Microsoft Corporation.

Linux is a U.S. registered trademark of Linus Torvalds.

UNIX is a registered trademark of The Open Group.

Printed in the US

Edge Switch 2/24 installation guide

---

# Contents

About this guide . . . . .	9
Intended audience . . . . .	9
Related documentation . . . . .	9
Document conventions and symbols . . . . .	10
Rack stability . . . . .	11
HP technical support . . . . .	11
HP-authorized reseller . . . . .	11
Helpful web sites . . . . .	12
1 Switch features . . . . .	13
Edge Switch 2/24 description . . . . .	13
Field replaceable units (FRUs) . . . . .	14
Front panel features . . . . .	14
Power and system error LEDs . . . . .	15
Ethernet LAN connector . . . . .	15
Initial machine load button . . . . .	16
SFP transceivers (Fibre Channel ports) . . . . .	16
Port LEDs . . . . .	16
Rear panel features . . . . .	17
Power supplies . . . . .	17
Maintenance port . . . . .	18
Switch management . . . . .	18
Embedded Web Server (EWS) . . . . .	18
High Availability-Fabric Manager and Element Manager . . . . .	18
Remote workstations . . . . .	19
LAN interface options . . . . .	19
Minimum remote workstation requirements . . . . .	19
Command line interface . . . . .	20
Operational features . . . . .	20
Error-detection, reporting, and serviceability features . . . . .	20
Management Appliance . . . . .	22
Zoning . . . . .	23
Multi-switch fabrics . . . . .	23
Software diagnostics . . . . .	24
Optional kits . . . . .	24
2 Installing and configuring the Edge Switch 2/24. . . . .	27
Installation options . . . . .	27
Review installation requirements . . . . .	27
Unpack and Inspect the switch . . . . .	28
Install the Edge Switch on a desktop . . . . .	28

Install the Edge Switch in a rack . . . . .	29
Rack mount checklist . . . . .	30
Mounting hardware . . . . .	30
Brackets and rails . . . . .	30
Required tools . . . . .	31
Mounting the adjustable brackets in the rack. . . . .	31
Mounting the slide rails on the sides of the switch . . . . .	32
Installing the switch in the cabinet . . . . .	33
Configure switch network information . . . . .	34
Changing the switch address . . . . .	34
LAN-Connect the switch. . . . .	38
Configure the HAFM appliance . . . . .	39
Record or verify HAFM appliance restore information . . . . .	39
Enabling HAFM to manage the switch . . . . .	39
Verify communication between switch and HAFM appliance. . . . .	40
Set switch date and time. . . . .	42
Set date and time manually. . . . .	42
Periodically Synchronize date and time . . . . .	43
Frequently used HAFM settings. . . . .	43
Set the switch online . . . . .	44
Set the switch offline . . . . .	44
Configure switch identification . . . . .	44
Configure switch operating parameters . . . . .	45
Switch parameters . . . . .	46
Domain ID . . . . .	46
Preferred. . . . .	46
Insistent . . . . .	46
Rerouting delay . . . . .	47
Domain RSCNs . . . . .	47
Suppress RSCNs on zone set activations. . . . .	47
Configure fabric operating parameters. . . . .	48
Fabric parameters. . . . .	49
R_A_TOV . . . . .	49
E_D_TOV . . . . .	49
Switch priority . . . . .	49
Interop Mode . . . . .	50
Configure switch binding . . . . .	50
Configure SNMP trap message recipients. . . . .	52
Configure, enable, and test e-mail notification. . . . .	53
Configure and enable Ethernet events . . . . .	54
Configure call home event notification . . . . .	54
Configure threshold alerts. . . . .	54
Create new alerts . . . . .	55
Modify alerts . . . . .	58
Activate or deactivate alerts . . . . .	59
Delete alerts. . . . .	59

Configure SANtegrity authentication . . . . .	59
Back up HAFM configuration data . . . . .	60
Configure open systems management appliance . . . . .	60
Configure feature key . . . . .	61
Configure Open Trunking . . . . .	61
Enable Embedded Web Server . . . . .	61
Enable Telnet . . . . .	61
Connect cables to Fibre Channel ports . . . . .	61
Connect the switch to a fabric . . . . .	62
Unpack, inspect, and install the ethernet hub (optional) . . . . .	63
Using HAFM from a remote location . . . . .	64
Remote workstation minimum requirements . . . . .	64
Install HAFM client on a remote workstation . . . . .	64
Launch HAFM from the remote client . . . . .	65
<b>3 Using the Embedded Web Server . . . . .</b>	<b>67</b>
Accessing the Embedded Web Server . . . . .	67
Configure switch ports . . . . .	68
Configure Switch Identification . . . . .	70
Configure date and time . . . . .	71
Configure switch and fabric parameters . . . . .	71
Configure switch parameters . . . . .	71
Set fabric parameters . . . . .	73
Configure network information . . . . .	74
Configure SNMP trap message recipients . . . . .	76
Enable or disable the CLI . . . . .	77
Configure user rights . . . . .	78
<b>4 Manage firmware versions . . . . .</b>	<b>79</b>
Determine a switch firmware version . . . . .	79
Add a firmware version . . . . .	80
Modify a firmware version description . . . . .	82
Delete a firmware version . . . . .	82
Download a firmware version to a switch . . . . .	83
Back up the configuration . . . . .	85
<b>A Regulatory compliance and safety . . . . .</b>	<b>87</b>
Regulatory compliance . . . . .	87
Federal Communications Commission notice . . . . .	87
Class A equipment . . . . .	88
Class B equipment . . . . .	88
Declaration of conformity for products marked with the FCC logo, United States only . . . . .	88
Modifications . . . . .	88
Cables . . . . .	89
Regulatory compliance identification numbers . . . . .	89

Laser device . . . . .	89
Laser safety warning . . . . .	89
Certification and classification information . . . . .	89
Laser product label . . . . .	90
International notices and statements . . . . .	90
Canadian notice (avis Canadien) . . . . .	90
Class A equipment . . . . .	90
Class B equipment . . . . .	90
European Union notice . . . . .	90
BSMI notice . . . . .	91
Japanese notice . . . . .	91
Korean notices . . . . .	92
Safety . . . . .	92
Battery replacement notice . . . . .	92
Taiwan battery recycling notice . . . . .	93
Power cords . . . . .	93
Japanese power cord notice . . . . .	93
Electrostatic discharge . . . . .	93
Preventing electrostatic damage . . . . .	93
Grounding methods . . . . .	94
<b>B Technical specifications . . . . .</b>	<b>95</b>
Factory defaults . . . . .	95
Physical dimensions . . . . .	97
Environmental specifications . . . . .	97
Power requirements . . . . .	98
Operating tolerances . . . . .	98
Laser information . . . . .	99
<b>Index . . . . .</b>	<b>101</b>
<b>Figures</b>	
1 Edge Switch 2/24 (front view) . . . . .	14
2 Edge Switch 2/24 front panel features . . . . .	15
3 Edge Switch 2/24 (rear view) . . . . .	17
4 Management appliance main window . . . . .	22
5 Brackets included in kit . . . . .	31
6 Attaching the slide rail to the switch . . . . .	33
7 Connection Description dialog box . . . . .	35
8 Connect To dialog box . . . . .	35
9 Port Settings dialog box . . . . .	36
10 HyperTerminal window . . . . .	37
11 Disconnect Now dialog box . . . . .	38
12 Save Session dialog box . . . . .	38
13 Discover Setup dialog box . . . . .	39
14 Domain Information dialog box (IP Address page) . . . . .	40
15 Switch Hardware View page . . . . .	41
16 Configure Date and Time dialog box . . . . .	42

17	Configure Identification dialog box . . . . .	44
18	Configure Switch Parameters dialog box . . . . .	45
19	Configure Fabric Parameters dialog box. . . . .	48
20	Configure Preferred Paths dialog box. . . . .	51
21	Add Preferred Path dialog box . . . . .	51
22	Configure SNMP Agent dialog box . . . . .	52
23	Configure E-Mail dialog box . . . . .	53
24	Configure Ethernet Events dialog box . . . . .	54
25	Configure Threshold Alerts dialog box . . . . .	55
26	New Threshold Alerts dialog box—first screen . . . . .	56
27	New Threshold Alerts dialog box—second screen . . . . .	56
28	New Threshold Alerts dialog box—third screen . . . . .	57
29	New Threshold Alerts dialog box—summary screen. . . . .	58
30	Configure Threshold Alerts dialog box—alert activated . . . . .	58
31	SANtegrity Authentication dialog box . . . . .	60
32	Port Properties dialog box. . . . .	63
33	HAFM remote client install . . . . .	64
34	Enter Network Password dialog box . . . . .	67
35	Embedded Web Server interface—View window . . . . .	68
36	Block or unblock a port from the Configure window. . . . .	69
37	Configure Switch Identification tab . . . . .	70
38	Switch page—Date/Time tab . . . . .	71
39	Switch page—Parameters tab . . . . .	72
40	Switch page—Fabric parameters tab . . . . .	73
41	Switch page—Network tab. . . . .	75
42	Network configuration changes activated . . . . .	75
43	Management page—SNMP tab . . . . .	76
44	Management page—CLI tab . . . . .	77
45	Security page—Auth User tab. . . . .	78
46	Firmware Library dialog box . . . . .	79
47	Firmware Library dialog box . . . . .	81
48	New Firmware Version dialog box . . . . .	81
49	New Firmware Description dialog box . . . . .	81
50	Modify Firmware Description dialog box . . . . .	82
51	Send Firmware Warning dialog box . . . . .	84
52	Backup and Restore Configuration dialog box. . . . .	85
53	Information dialog box. . . . .	85
54	Class 1 laser product label . . . . .	90

## Tables

1	Document conventions . . . . .	10
2	Edge Switch 2/24 optional kits. . . . .	24
3	Switch operational states and symbols . . . . .	40
4	Factory-set defaults. . . . .	95
5	Switch factory-default values for reset configuration option . . . . .	95
6	Dimensions . . . . .	97
7	Environmental specifications . . . . .	97

8	Power requirements . . . . .	98
9	Operating tolerances . . . . .	98
10	Laser specifications–2 Gb. . . . .	99



---

## About this guide

This guide provides information about:

- Installing the Edge Switch 2/24
- Performing initial configuration of the switch

## Intended audience

This guide is intended for use by administrators who are familiar with the following:

- Fibre Channel technology
- HP StorageWorks Fibre Channel switches

## Related documentation

For a list of corresponding documentation included with this product, see the *Related documents* section of the *HP StorageWorks Edge Switch release notes*.

For the latest information, documentation, and firmware releases, please visit the HP StorageWorks web site:

<http://h18006.www1.hp.com/storage/saninfrastructure.html>





For information about Fibre Channel standards, visit the Fibre Channel Industry Association web site:

<http://www.fibrechannel.org>

# Document conventions and symbols

**Table 1** Document conventions

Convention	Element
Medium blue text: <a href="#">Figure 1</a>	Cross-reference links and e-mail addresses
Medium blue, underlined text ( <a href="http://www.hp.com">http://www.hp.com</a> )	Web site addresses
<b>Bold font</b>	<ul style="list-style-type: none"><li>• Key names</li><li>• Text typed into a GUI element, such as into a box</li><li>• GUI elements that are clicked or selected, such as menu and list items, buttons, and check boxes</li></ul>
<i>Italics font</i>	Text emphasis
Monospace font	<ul style="list-style-type: none"><li>• File and directory names</li><li>• System output</li><li>• Code</li><li>• Text typed at the command-line</li></ul>
<i>Monospace, italic font</i>	<ul style="list-style-type: none"><li>• Code variables</li><li>• Command-line variables</li></ul>
<b>Monospace, bold font</b>	Emphasis of file and directory names, system output, code, and text typed at the command line

-  **WARNING!** Indicates that failure to follow directions could result in bodily harm or death.
-  **CAUTION:** Indicates that failure to follow directions could result in damage to equipment or data.
-  **IMPORTANT:** Provides clarifying information or specific instructions.
-  **NOTE:** Provides additional information.


---

 **TIP:** Provides helpful hints and shortcuts.

---

## Rack stability

---

 **WARNING!** To reduce the risk of personal injury or damage to equipment:

- Extend leveling jacks to the floor.
  - Ensure that the full weight of the rack rests on the leveling jacks.
  - Install stabilizing feet on the rack.
  - In multiple-rack installations, secure racks together.
  - Extend only one rack component at a time. Racks may become unstable if more than one component is extended.
- 

## HP technical support

Telephone numbers for worldwide technical support are listed on the HP support web site:  
<http://www.hp.com/support/>.

Collect the following information before calling:

- Technical support registration number (if applicable)
- Product serial numbers
- Product model names and numbers
- Applicable error messages
- Operating system type and revision level
- Detailed, specific questions

For continuous quality improvement, calls may be recorded or monitored.

HP strongly recommends that customers sign up online using the Subscriber's choice web site at  
<http://www.hp.com/go/e-updates>.

- Subscribing to this service provides you with e-mail updates on the latest product enhancements, newest versions of drivers, and firmware documentation updates as well as instant access to numerous other product resources.
- After signing up, you can quickly locate your products by selecting **Business support** and then **Storage** under Product Category.

## HP-authorized reseller

For the name of your nearest HP-authorized reseller:

- In the United States, call 1-800-345-1518.
- Elsewhere, visit the HP web site: <http://www.hp.com>. Then click **Contact HP** to find locations and telephone numbers.

## Helpful web sites

For third-party product information, see the following HP web sites:

- <http://www.hp.com>
- <http://www.hp.com/go/storage>
- <http://www.hp.com/support/>
- <http://www.docs.hp.com>

---

# 1 Switch features

The HP StorageWorks Edge Switch 2/24 provides dynamic switched connections between Fibre Channel servers and devices in a storage area network (SAN) environment. SANs introduce the concept of server-to-device networking and multi-switch fabrics, eliminate requirements for dedicated connections, and enable the enterprise to become data centric.

A SAN provides speed, high capacity, and flexibility for the enterprise, and is primarily based upon Fibre Channel architecture. The switch implements Fibre Channel technology that provides a bandwidth of 2.125 Gbps, redundant switched data paths, a scalable number of active ports, and long transmission distances.

This chapter describes the switch and attached HP StorageWorks HA-Fabric Manager appliance (HAFM). The chapter specifically discusses:

- [Edge Switch 2/24 description](#), page 13
- [Switch management](#), page 18
- [Operational features](#), page 20
- [Optional kits](#), page 24


## Edge Switch 2/24 description

The Edge Switch 2/24 provides Fibre Channel connectivity through 24 generic mixed ports (GX\_Ports). Switch ports can be configured as:

- Fabric ports (F\_Ports) to provide direct connectivity for up to 24 switched fabric devices.
- Fabric loop ports (FL\_Ports) to provide arbitrated loop connectivity and fabric attachment for FC-AL devices. Each FL\_Port can theoretically support the connection of 126 FC-AL devices.
- Expansion ports (E\_Ports) to provide interswitch link (ISL) connectivity to fabric directors and switches.

The switch, shown in [Figure 1](#) on page 14, provides dynamic switched connections for servers and devices, supports mainframe and open-systems interconnection (OSI) computing environments, and provides data transmission and flow control between device node ports (N\_Ports) as dictated by the Fibre Channel Physical and Signaling Interface (FC-PH 4.3). Through interswitch links (ISLs), the switch can connect additional switches to form a Fibre Channel multi-switch fabric.

The switch provides connectivity for devices manufactured by multiple original equipment manufacturers (OEMs). To determine if an OEM product can communicate through connections provided by the switch, or if communication restrictions apply, refer to the supporting publications for the product or contact your HP marketing representative.



**Figure 1** Edge Switch 2/24 (front view)

## Field replaceable units (FRUs)


The switch provides a modular design that enables quick removal and replacement of FRUs, including small form factor pluggable (SFP) optical transceivers and power supply assemblies with internal cooling fans. Edge Switch 2/24 FRUs are detailed in the front and rear panel feature descriptions.

## Front panel features

Connectors and indicators include the:

- Combined initial machine load and reset (IML/RESET) button.
- Ethernet LAN connector.
- Green power (PWR) and amber system error (ERR) LEDs.
- Green, blue, and amber status LEDs associated with FRUs.

Figure 2 shows the front panel controls, connectors and indicators.



- |                          |                                     |
|--------------------------|-------------------------------------|
| 1 Power LED (green)      | 4 Initial machine load (IML) button |
| 2 Error LED (amber)      | 5 SFP fiber optic connectors        |
| 3 Ethernet LAN connector | 6 Port LEDs                         |

**Figure 2** Edge Switch 2/24 front panel features

### Power and system error LEDs

The Power LED, as shown in Figure 2, illuminates when the switch is connected to facility AC power and powered on. If the LED extinguishes, a facility power source, power cord, or power distribution failure is indicated.

The Error LED, as shown in Figure 2, illuminates when the switch detects an event requiring immediate operator attention, such as a FRU failure. The LED remains illuminated as long as an event is active. The LED extinguishes when the Clear System Error Light function is selected from the Product Manager application.

The LED blinks if unit beaconing is enabled. An illuminated LED (indicating a failure) takes precedence over unit beaconing. The LED also blinks (at twice the beaconing rate) when the IML/RESET button is pressed and held for more than three seconds.

### Ethernet LAN connector

The front panel provides a 10/100 megabit per second (Mbps) RJ-45 twisted-pair connector that attaches to an Ethernet LAN to provide communication with the HAFM appliance or an SNMP management workstation. Two green LEDs are associated with the LAN connector. When illuminated, the left LED indicates LAN operation at 10 Mbps, and the right LED indicates LAN operation at 100 Mbps.

## Initial machine load button

The IML/RESET button is shown in [Figure 2](#) on page 15. When the IML/RESET button is pressed, held for three seconds, and released, the switch performs an initial machine load that reloads the firmware from FLASH memory. This operation is not disruptive to Fibre Channel traffic. If the button is held for more than three seconds, the ERR LED blinks at twice the unit beaconing rate.

When the IML/RESET button is pressed and held for ten seconds, the switch performs a reset. After three seconds, the ERR LED blinks at twice the unit beaconing rate. A reset is disruptive and resets the:

- Microprocessor and functional logic for the CTP card and reloads the firmware from FLASH memory.
- Ethernet LAN interface, causing the connection to the HAFM appliance to drop momentarily until the connection automatically recovers.
- Ports, causing all Fibre Channel connections to drop momentarily until the connections automatically recover. This causes attached devices to log out and log back in; therefore data frames lost during switch reset must be retransmitted.

A reset should only be performed if a CTP card failure is indicated. As a precaution, the IML/RESET button is flush mounted to protect against inadvertent activation.

## SFP transceivers (Fibre Channel ports)

The Edge Switch 2/24 provides 24 Fibre Channel ports. A single-mode or multi-mode fiber optic cable attaches to a port through a small form factor pluggable (SFP) transceiver. The SFP provides a duplex LC interface, and can be detached from the switch port for easy replacement.

The following fiber optic transceiver types are available:

- Shortwave laser—Shortwave laser SFPs provide short-distance connections (2 to 500 meters) through 50-micron or 62.5-micron multi-mode fiber.
- Longwave laser—Longwave laser SFPs provide long-distance connections (up to 10 kilometers) through 9-micron single-mode fiber.
- Extended longwave laser—Two types of extended longwave laser transceivers provide connections for transferring 2.125 Gbps data up to 20 kilometers or 35 kilometers through 9-micron single-mode fiber.

## Port LEDs


Amber and green/blue LEDs to the left of each Fibre Channel port illuminate, extinguish, or blink to indicate port status and port speed.

- Amber LED—illuminates if the port fails.
- Green/blue LED—illuminates green to indicate 1.0625 Gbps port operation. Illuminates blue to indicate 2.125 Gbps port operation.



## Rear panel features

The switch provides a modular design that enables quick removal and replacement of field-replaceable power supply assemblies with internal cooling fans. [Figure 3](#) illustrates the rear of the switch.



1 Power supplies with internal cooling fans (2)

2 Maintenance port

**Figure 3** Edge Switch 2/24 (rear view)

## Power supplies

The switch contains two power supply assemblies with internal cooling fans. The redundant, load-sharing power supply assemblies step down and rectify facility input power to provide 3.3 volts direct current (VDC), 5 VDC, and 12 VDC to the control processor (CTP) card. The power supplies also provide input filtering, overvoltage protection, and overcurrent protection. An amber LED on each assembly illuminates if the FRU fails.

Either power supply can be replaced while the switch is operational. Each power supply has a separate connection to the CTP card to allow for independent AC power sources. The power supplies are input rated at 90 to 264 volts alternating current (VAC).

Three cooling fans integrated in each power supply assembly (six fans total) provide cooling for the power supplies and CTP card, as well as redundancy for continued operation if a single fan fails. Fans are removed and replaced as part of the integrated power supply.

Power supply requirements are listed in "[Technical specifications](#)" on page 95.

## Maintenance port

The rear panel provides a 9-pin DSUB maintenance port, as shown in [Figure 3](#) on page 17, that provides a connection for a local terminal or dial in connection for a remote terminal. Although the port is typically used by authorized maintenance personnel, operations personnel can use the port to configure switch network addresses.

## Switch management

The switch is managed and controlled through a:

- Customer-supplied PC platform with an Internet connection to the Embedded Web Server (EWS) interface on the switch. Using this graphical user interface (GUI), operators can quickly view switch status. The interface also allows service personnel to perform configuration tasks, view system alerts and related log information, and monitor switch status, port status, and performance. FRU status and system alert information are highly visible.
- Optional High Availability Fabric Manager (HAFM) appliance with the Java™ based Edge Switch 2/24 HAFM Element Manager installed. The HAFM appliance provides a central point of control for up to 48 edge switches or directors.
- Customer-supplied remote workstation communicating with the HAFM appliance through a corporate intranet.

## Embedded Web Server (EWS)

Administrators or operators with a browser-capable PC and a LAN to which the switch is connected can monitor and manage the switch through the EWS interface. The EWS interface manages only a single switch, and provides a graphical user interface (GUI) that supports product configuration, statistics monitoring, and basic operation. The EWS interface is opened from a standard web browser running Netscape Navigator 4.6 or later or Microsoft® Internet Explorer 4.0 or later.

At the browser, enter the Internet Protocol (IP) address of the switch as the Internet uniform resource locator (URL). When prompted at a login screen, enter a user name and password.

Refer to the *HP StorageWorks Embedded Web Server user guide* for more information.

## High Availability-Fabric Manager and Element Manager

As an option, the switch can be managed through an High Availability-Fabric Manager (HAFM) appliance running the Edge Switch 2/24 Product Manager application. Multiple switches and the HAFM appliance communicate on a local area network (LAN) through one or more 10/100 Base-T Ethernet hubs. One or more 24-port Ethernet hubs are optional and can be ordered with the switch. Up to three hubs are daisy-chained as required to provide additional Ethernet connections as more switches (or other HP managed products) are installed on a customer network.

The HAFM appliance provides a central point of control for up to 48 LAN-connected directors or edge switches.

The server is mounted in a slide-out drawer in the HP-supplied equipment rack. The HAFM appliance or Ethernet access to the EWS interface is required to install, configure, and manage the Edge Switch 2/24.

Although a configured switch operates normally without HAFM appliance intervention, an attached server should operate at all times to monitor switch operation, log events and configuration changes, and report failures.

The HAFM appliance provides an auto-detecting 10/100 Mbps LAN connection to the customer's public intranet to allow access from remote user workstations.

## Remote workstations

Using a standard web browser, the HAFM and client applications can be downloaded and installed on remote user workstations that are LAN-attached to the HAFM appliance. Operators at these workstations can manage and monitor switches controlled by the HAFM appliance. A maximum of nine concurrent users (eight remote users and one local user) can log in to the HAFM application running on the HAFM appliance. Each remote workstation must have access to the LAN segment on which the HAFM appliance is installed. Switch administrative functions are accessed through the LAN and HAFM appliance.

### LAN interface options

The LAN interface can be:

- Part of the dedicated 10/100 Mbps segment that provides access to managed switches. This switch-to-HAFM appliance connection is part of the required equipment installation. Connection of remote workstations can be through an Ethernet hub or through the customer intranet. If only one HAFM appliance connection is used and this connection is provided through the customer intranet, functions provided by the HAFM appliance are available to all users. Dual LAN connections provide a dedicated LAN segment that isolates the HAFM appliance and managed switches from unauthorized users.
- Part of a second HAFM appliance interface that connects to a customer intranet and allows operation of the HAFM application from remote user PCs or workstations. Connection to this LAN segment is optional and depends on customer requirements.

### Minimum remote workstation requirements

Client HAFM applications download and install to remote workstations (from the HAFM appliance) using a standard web browser. The applications operate on platforms that meet the following minimum system requirements:

- Desktop or notebook PC with color monitor, keyboard, and mouse, using an Intel® III processor with a 700 MHz or greater clock speed, and using the Microsoft Windows® 2000 (with Service Pack 4), Windows XP, Windows NT® 4.0 (with Service Pack 6a), or Windows Server 2003.
- UNIX® workstation with color monitor, keyboard, and mouse, using a:
  - Linux® based system using an Intel Pentium III processor with 1 GHZ or greater clock speed, using Red Hat 7.3 or later operating system.
  - Hewlett-Packard HA PA-RISC processor with a 400 MHz or greater clock speed, using the HP-UX 11 or later operating system.

- Sun Microsystems UltraSPARC II processor with a 400 MHz or greater clock speed, using the SunOS Version 7 or later operating system.
- IBM Power3-II microprocessor with a 333 MHz or greater clock speed, using the AIX Version 4.3.3 or later operating system.
- At least 150 MB for Windows-based system or 350 MB for UNIX-based systems available on the internal hard drive.
- 512MB or greater RAM.
- Video card supporting 256 colors at 800 x 600 pixel resolution.
- Ethernet network adapter.
- Java enabled Internet browser, such as Microsoft Internet Explorer (Version 4.0 or later) or Netscape Navigator (Version 4.6 or later).

Refer to the HAFM appliance installation guide and the *HP StorageWorks High Availability-Fabric Manager user guide* for more information.

## Command line interface

The command line interface (CLI) allows you to access many HAFM functions while entering commands during a Telnet session with the switch. The primary purpose of the CLI is to automate management of a large number of switches using scripts. The CLI is not an interactive interface; no checking is done for pre-existing conditions and no prompts display to guide users through tasks.

Refer to *HP StorageWorks CLI reference guide for directors and edge switches* for more information.

## Operational features

The Edge Switch 2/24 supports several operational features including:

- Advanced error detection, reporting, and serviceability.
- Support for multi-switch fabrics.
- Software diagnostics to aid in fault isolation and repair.

## Error-detection, reporting, and serviceability features

The switch provides the following error detection, reporting, and serviceability features:

- Light-emitting diodes (LEDs) on switch FRUs and adjacent to Fibre Channel ports that provide visual indicators of hardware status or malfunctions.
- FRUs (SFP transceivers and integrated cooling fan and power supply assemblies) that are removed or replaced without disrupting switch or Fibre Channel link operation.
- A modular design that enables quick removal and replacement of FRUs without the use of tools or equipment.
- System alerts and logs that display switch, Ethernet link, and Fibre Channel link status at the EWS interface, HAFM appliance, or remote workstation.
- Diagnostic software that performs power-on self-tests (POSTs) and port diagnostics (loopback tests).

- An RS-232 maintenance port at the rear of the switch (port access is password-protected) that enables installation or service personnel to change the switch's IP address, subnet mask, and gateway address.  
These parameters can also be changed through a Telnet session, access for which is provided through a local or remote PC with an Internet connection to the switch.
- Data collection through the EWS interface or Element Manager of the HAFM applications to help isolate system problems. The data includes a memory dump file and audit, hardware, and engineering logs.
- Beaconing to assist service personnel in locating a specific port or switch. When port beaconing is enabled, the amber LED associated with the port flashes. When unit beaconing is enabled, the system error indicator on the front panel flashes. Beaconing does not affect port or switch operation.
- Automatic notification of significant system events (to support personnel or administrators) through e-mail messages or the call-home feature.
- SNMP management using the Fibre Channel Fabric Element MIB (v3.1), TCP/IP MIB-II definition (RFC 1213), or a product-specific MIB that runs on the switch. Up to six authorized management workstations can be configured through the EWS interface and Element Manager to receive unsolicited SNMP trap messages. The trap messages indicate product operational state changes and failure conditions.
- Optional SNMP management using the Fibre Alliance MIB that runs on the HAFM appliance. Up to 12 authorized management workstations can be configured through the HAFM server to receive unsolicited SNMP trap messages. The trap messages indicate operational state changes and failure conditions.




**NOTE:** For more information about SNMP support provided by Hewlett-Packard products, refer to the *HP StorageWorks SNMP reference guide for directors and edge switches*.

---

## Management Appliance

The HAFM appliance and Element Manager provide a GUI to manage, monitor, and isolate problems for multiple switches and multiswitch fabrics. The server and client applications operate on the management appliance, and a user interface is provided through an Ethernet LAN-attached PC or workstation running client-only applications as shown in [Figure 4](#).



**Figure 4** Management appliance main window

The main window provides:

- Menu bar—Commands at the top of the window provide drop-down menu selections to perform functions for SAN devices including editing, viewing, planning, discovery, configuration, and monitoring.
- Tool bar—The tool bar (below the menu bar) provides button selections to perform SAN management tasks including opening a SAN configuration, configuring users, setting up and starting the device discovery process, configuring zoning, displaying a SAN, displaying SAN utilization, and viewing reports.
- View tab—Select the View tab to display a product list and physical map of the discovered topology.
- Product list—When the View tab is selected, the product list at the left side of the window displays a list of discovered devices and associated properties.
- Physical map—When the View tab is selected, the physical map at the right side of the window depicts the SAN topology, discovered devices, and color-coded links.
- Tool box—The toolbox at the right side of the window provides button selections to change the discovered topology display, including zoom in, zoom out, expand, and collapse functions.


- Master log—The master log at the lower left corner of the window displays a list of informational, warning, or fatal events. The log also includes the event source, type, description, time, and IP address of the device generating the event.
- Utilization legend—The color-coded utilization legend explains percent utilization for links depicted on the physical map.
- Minimap—The minimap at the lower right corner of the window displays the entire SAN topology, and provides an aid to navigate the more detailed physical map.
- Status bar—The status bar at the bottom of the window displays connection status, client information, user level, and discovery status.

## Zoning

The switch supports a name server zoning feature that partitions attached devices into restricted-access groups called zones. Devices in the same zone can recognize and communicate with each other through switched port-to-port connections. Devices in separate zones cannot communicate with each other.

Zoning is configured by authorizing or restricting access to name server information associated with device N\_Ports that attach to switch fabric ports (F\_Ports). A zone member is specified by the port number to which a device is attached, or by the 8-byte (16-digit) World Wide Name (WWN) assigned to the host bus adapter (HBA) or Fibre Channel interface installed in a device. A device can belong to multiple zones.

---

 **NOTE:** By default, zoning is disabled. You must enable zoning to see devices.

---

---

△ **CAUTION:** If zoning is implemented by port number, a change to the switch fiber optic cable configuration disrupts zone operation and may incorrectly include or exclude a device from a zone.

If zoning is implemented by WWN, removal and replacement of a device HBA or Fibre Channel interface (thereby changing the device WWN) disrupts zone operation and may incorrectly include or exclude a device from a zone.

In Open Fabric mode, only zoning by WWN is supported. Zoning by port numbers is not.

---

Zones are grouped into zone sets. A zone set is a group of zones that is enabled (activated) or disabled across all switches in a multi-switch fabric. Only one zone set can be enabled at one time.

## Multi-switch fabrics

A Fibre Channel topology that consists of one or more interconnected switches or switch elements is called a fabric. Operational software provides the ability to interconnect switches (through expansion port (E\_Port) connections) to form a multi-switch fabric. The data transmission path through the fabric is typically determined by fabric elements and is user-transparent. Subject to zoning restrictions, devices attached to any interconnected switch can communicate with each other through the fabric.

## Software diagnostics

The switch provides the following diagnostic software features that aid in fault isolation and repair of problems:

- FRUs provide on-board diagnostic and monitoring circuits that continuously report FRU status to the EWS, and HAFM applications. These applications provide system alerts and logs that display failure and diagnostic information at the HAFM appliance or a remote workstation communicating with the HAFM appliance.
- The HAFM Services application that runs as a Windows service and provides an additional user interface to display operational status.
- The EWS interface that provides Ethernet access to isolate problems for a single switch.
- Unsolicited SNMP trap messages that indicate operational state changes or failures can be transmitted to up to 12 authorized management workstations on an HAFM appliance, and up to 6 authorized management workstations on an edge switch or director.
- E-mail messages or call-home reports that provide automatic notification of significant system events to designated support personnel or administrators.

## Optional kits

Contact your Hewlett-Packard authorized service provider to purchase the following optional Edge Switch 2/24 kits described in [Table 2](#).

**Table 2** Edge Switch 2/24 optional kits

Supporting Kit	Description
8-flexport upgrade for Edge Switch 2/24 Part Number: 316096-B21	Used to upgrade the Edge Switch 2/24 from: <ul style="list-style-type: none"><li>• 8 to 16 ports</li><li>• 16 to 24 ports.</li></ul>
Edge Switch 2/24 Product Manager License Part Number: 317067-B21	Used when switch is managed through HAFM.
HP Open Trunking License Part Number: 336002-B21	Provides a license to use the Open Trunking feature.
HP SANtegrity Binding License Part Number: 317073-B21	Provides a license to use the SANtegrity Binding feature.
2Gb UPM Port Module Kit Part Number: 316094-B21	Provides 4 additional short-wave ports for the Edge Switch 2/24.
300m Optical Transceiver Kit Part Number: 300834-B21	Provides short-wave optical transceiver for the Edge Switch 2/24.



**Table 2** Edge Switch 2/24 optional kits (continued)

Supporting Kit	Description
10km Long Distance Optical Transceiver Kit Part Number: 300835-B21	Provides 10 km long-wave optical transceiver for the Edge Switch 2/24.
35 km Extended Reach Optical Transceiver Kit Part Number: 300836-B21	Provides 35 km long-wave optical transceiver for the Edge Switch 2/24.



---

## 2 Installing and configuring the Edge Switch 2/24

This chapter describes tasks to install, configure, and verify operation of the Edge Switch 2/24. This chapter includes the following topics:

- [Installation options](#), page 27
- [Review installation requirements](#), page 27
- [Unpack and Inspect the switch](#), page 28
- [Install the Edge Switch on a desktop](#), page 28
- [Install the Edge Switch in a rack](#), page 29
- [Configure switch network information](#), page 34
- [LAN-Connect the switch](#), page 38
- [Configure the HAFM appliance](#), page 39
- [Frequently used HAFM settings](#), page 43
- [Connect the switch to a fabric](#), page 62
- [Unpack, inspect, and install the ethernet hub \(optional\)](#), page 63
- [Using HAFM from a remote location](#), page 64

### Installation options

The Edge Switch is installed in one of two configurations. The options are:

- **Table or desktop**—One or more Edge Switches, an optional HAFM appliance, and an optional Ethernet hub are installed at the customer facility on a desk or table top. Ethernet cabling distance, and local area network (LAN) addressing issues must be considered.
- **Customer-supplied equipment rack**—One or more Edge Switches, an optional HAFM appliance, and an optional Ethernet hub are installed in a customer-supplied equipment rack. Rack-mount hardware is provided in the shipping container. Ethernet cabling, distance, and LAN addressing issues must be considered.

### Review installation requirements

Verify that the following requirements are met prior to Edge Switch and HAFM appliance installation. Ensure:

- A site plan is prepared, configuration planning tasks are complete, planning considerations are evaluated, and related planning checklists are complete. Fabric and device connectivity are evaluated, and the related planning worksheet is complete. Refer to the *HP StorageWorks HA-Fabric Manager user guide*.
- Support is available for one of the following Edge Switch management methods:
  - A browser-capable PC or Linux system and Ethernet connectivity to support Edge Switch management through the EWS interface
  - The HAFM appliance and LAN segment connectivity to support Edge Switch management through the HAFM and Element Manager.

- Support equipment and personnel are available for the installation.
- The required number and type of fiber optic jumper cables are delivered and available.
- Ensure that the cables are the correct length with the required connectors.
- A customer-supplied equipment rack and associated hardware are available (optional).
- Remote workstations or simple network management protocol (SNMP) workstations are available (optional). Workstations are customer-supplied and connected through a corporate or dedicated LAN.

## Unpack and Inspect the switch

This section provides instructions for unpacking and inspecting the Edge Switch 2/24 prior to installing it in a desktop or rack-mount configuration.

To unpack and inspect the switch:

- 
- △ **CAUTION:** When you remove the Edge Switch from the carton, do not rest it on its rear window while examining it. To do so may break the FRU handles.
- 

1. Inspect the shipping containers for damage caused during transit. If a container is damaged, ensure that a representative from the freight carrier is present when the container is opened.
2. Unpack the shipping containers and inspect each item for damage. Save all shipping and packing materials. Ensure that all items on the enclosed shipping list are in each container.
3. If any items are damaged or missing, customers should contact an HP-authorized service provider or reseller.

## Install the Edge Switch on a desktop

To install and configure the Edge Switch on a desktop:

1. Remove the backing from the four adhesive rubber pads and apply the pads to the underside of the Edge Switch.
2. Ensure that the pads are aligned with the scribed circles at each corner.
3. Position the Edge Switch on a table or desktop as directed by the customer. Ensure that:
  - Grounded AC electrical outlets are available.
  - Adequate ventilation is present.
  - Areas with excessive heat, dust, or moisture are avoided.
  - All planning considerations are met. Refer to the *HP StorageWorks HA-Fabric Manager user guide*.
4. Verify all field-replaceable units (FRUs), including small form factor pluggable (SFP) optical transceivers and combined cooling fan and power supply assemblies, are installed as ordered.

5. Connect the U.S. or country-specific (optional) AC power cords to the right (PS0) and left (PS1) receptacles at the rear of the chassis.

---

**⚠ WARNING!** An HP-supplied power cord is provided for each Edge Switch power supply. To prevent electric shock when connecting the Edge Switch to primary facility power, use only the supplied power cords, and ensure that the facility power receptacle is the correct type, supplies the required voltage, and is properly grounded.

---

6. Connect the remaining ends of the AC power cords to separate facility power sources that provide single-phase, 90 to 264 volt alternating current (VAC) current. This provides power redundancy.

When the first power cord is connected, the Edge Switch powers on and performs power-on self-tests (POSTs). During POSTs:

- a. The green power (PWR) LED on the front panel illuminates.
  - b. The amber system error (ERR) LED on the front panel blinks momentarily while the Edge Switch is tested.
  - c. The green LEDs associated with the Ethernet port blink momentarily while the port is tested.
  - d. The green/blue and amber LEDs associated with Fibre Channel ports blink momentarily while the ports are tested.
7. After successful POST completion, the green power (PWR) LED remains ON and all other front panel LEDs turn OFF.
  8. If a POST error or other malfunction occurs, refer to the *HP StorageWorks Edge Switch 2/24 service manual* to isolate the problem.
  9. Perform the following steps:
    - If you manage the switch through EWS, go to ["Using the Embedded Web Server"](#) on page 67 to configure the switch.
    - If you manage the switch through HAFM, go to ["Configure switch network information"](#) on page 34.

## Install the Edge Switch in a rack


This section describes how to rack mount the HP StorageWorks Edge Switch 2/24 in the appropriate HP, or comparable, 19-inch Electronic Industries Association (EIA) rack:

- HP 9000 series, 10000 series, and 11000 series racks
- HP rack system/e or 19-inch EIA rack

## Rack mount checklist

This section describes the contents of the rack mount kit as well as tools or equipment required to complete the installation.

---

 **NOTE:** The hardware kit includes parts not required for the configuration described in these instructions.

---


### Mounting hardware

- Two (2) two-hole bar nuts
- Six (6) three-hole bar nuts (only 4 used)
- Eight (8) square alignment washers (required only for HP 9000, 10000 and 11000 series racks)
- Eight (8) Phillips panhead screws (10-32 x 1/2) with split lock and flat washers
- Four (4) Phillips flathead screws (8-32 x 7/16)
- Ten (10) Phillips panhead screws (10-32 x 5/8) with flat washer (only 2 used)
- Six (6) Phillips flathead screws (6-32 x 3/8) (not used)
- Twelve (12) Phillips panhead screws (10-32 x 3/8) (not used)
- Four (4) 8-32 Keps nuts (not used)

### Brackets and rails

Brackets and rails included in the kit are shown in [Figure 5](#) on page 31.

- ❶ Two (2) fixed-length slide rails (one left and one right)
- ❷ Two (2) Front brackets
- ❸ Two (2) Rear brackets (long)
- ❹ Two (2) Rear spacing bracket
- ❺ Rear bracket (short)—not used in this configuration



**Figure 5** Brackets included in kit

## Required tools


The following tools are required, but are not included in the kit:

- Torque driver with a T10 Torx bit
- #2 Phillips screwdriver

## Mounting the adjustable brackets in the rack

Use these steps to install the adjustable brackets on the rack. You will need a #2 Phillips screwdriver and eight 10x32 panhead screws to complete this procedure.

---

 **NOTE:** If you are installing the Edge Switch 2/24 in an HP 9000, 10000 or 11000 series rack, you will need eight square alignment washers to complete this procedure.

---

1. Determine the position of the switch in the rack. Each Edge Switch 2/24 is 1.75 inches or 1U high.

2. Attach four bar nuts (three-hole bar nuts) to the cabinet frame using eight (8) Phillips panhead screws (10-32 x 1/2) with split lock and flat washers.

---

 **NOTE:** Do not install a screw in the center hole of each bar nut.


---

- a. If you are installing the Edge Switch 2/24 in an HP 9000, 10000, or 11000 series rack, place a square alignment washer on each panhead screw before inserting in the square cabinet frame holes.
  - b. Mount the bar nut on the inside of the cabinet frame. Orient the holes in the bar nut so that they are aligned closest to the inside edge of the cabinet frame.
  - c. Secure, but do not completely tighten, all screws.
3. Measure cabinet depth from inside edge to inside edge of the cabinet frame.
  4. Assemble two sets of front and rear brackets so that the combined brackets are equal to the depth of the cabinet.
  5. Attach a two-hole bar nut using four (4) Phillips flathead screws (8-32 x 7/16) to hold each assembled bracket together. Do not completely tighten but tighten enough to hold the brackets together.
  6. Install the assembled brackets in the cabinet by sliding the mounting brackets between the bar nut and cabinet frame.
  7. Tighten the three-hole bar nut screws on the mounting brackets to where the rails are stable, but can be easily adjusted.
  8. Securely tighten the two-hole bar nut screws holding the front and rear brackets together.

## Mounting the slide rails on the sides of the switch


Use these steps to install the slide rails on the sides of the switch as shown in [Figure 6](#) on page 33. You will need a torque driver with a T10 Torx bit (not supplied in the kit) and left and right slide rails to complete this procedure.

---

 **NOTE:** You may want to remove the Edge Switch 2/24 power supplies, as this will make the device lighter and easier to handle.

---


---

 **WARNING!** Before removing the power supplies, review the *HP StorageWorks Edge Switch 2/24 service manual* for details on removing power supplies.

---

1. On the Edge Switch 2/24, remove the six screws (three screws per side) that help hold the switch cover in place.


---

 **NOTE:** Do not discard these screws, as you will use them to attach the slide rails.

---



2. Using the torque driver and the screws you removed earlier, attach the left and right slide rails to the Edge Switch 2/24.



**Figure 6** Attaching the slide rail to the switch

## Installing the switch in the cabinet

Use these steps to install the switch in the cabinet. You will need a #2 Phillips screwdriver and two rear spacing brackets to complete this procedure.

1. From the front side of the cabinet, slide the switch into the mounting brackets and along the rails until the rear of the switch is flush with the rear of the cabinet.
2. Bring the rear spacing brackets to the rear of the cabinet.
3. Pull the switch toward the rear of the cabinet until it protrudes approximately 3 inches.
4. Orient the rear spacing bracket mounts so that they are pointed outward. Insert the tabs on each rear spacing bracket into the designated slots in each rail.
5. Push the switch forward using both rear spacing brackets until the rear spacing bracket mounts contact the cabinet rail.
6. Attach the rear spacing brackets to the cabinet using two Phillips panhead screws (10-32 x 5/8) with flat washer.
7. Ensuring that the square alignment washers are seated properly within the square cabinet frame holes, use a Phillips head screwdriver to tighten the rear and front mounting screws.

## Configure switch network information

The Edge Switch 2/24 is delivered with the following default network addresses:

- **MAC address**—The media access control (MAC) address is programmed into FLASH memory on the CTP card at the time of manufacture. The MAC address is unique for each Edge Switch, and should not be changed. The address is in `xx.xx.xx.xx.xx.xx` format. The `xxxx` is a hexadecimal pair.
- **IP address**—The factory preset default Internet Protocol (IP) address is 10.1.1.10. The default IP address is also 10.1.1.10.

If **Reset Configuration** is selected from the Element Manager application, the Edge Switch resets to the default address of 10.1.1.10.

If multiple Edge Switches are installed on the same LAN, each Edge Switch (and the HAFM appliance) must have a unique IP address. One Edge Switch can use the factory-set address, but the addresses of the remaining Edge Switches must be changed.

- **Subnet mask**—The default subnet mask is 255.0.0.0. If the switch is installed on a complex public LAN with one or more routers, the address may require change.
- **Gateway address**—the default gateway address is 0.0.0.0. If the switch is installed on a dedicated LAN with no connection through a router, the address does not require change. If the switch is installed on a public LAN (corporate intranet), the gateway address must be changed to the address of the corporate intranet's local router.

Verify that the type of LAN installation with the customer's network administrator. If one switch is installed on a dedicated LAN, network addresses do not require change.

## Changing the switch address

If multiple switches are installed or a public LAN segment is used, network addresses must be changed to conform to the customer's LAN addressing scheme. The following items are required to perform this task.

- A local workstation (desktop or notebook computer) with:
  - Microsoft Windows Server 2003, Windows 2000, Windows XP, Windows 98, or Windows NT 4.0 operating system.
  - RS-232 serial communication software (for example, ProComm Plus or HyperTerminal).

Note that the HAFM appliance may be used for this function and that HyperTerminal is included in the Windows operating system provided in the HAFM appliance.


- An asynchronous RS-232 null modem cable (provided with the switch).

Perform the following steps to change a switch's IP address, subnet mask, or gateway address:

1. Remove the protective plastic cover from the 9-pin maintenance port at the rear of the switch (a phillips-tip screwdriver is required). Connect the 9-pin end of the RS-232 null modem cable to the port.
2. Connect the other cable end to a 9-pin communication port (COM1 or COM2) at the rear of the maintenance terminal PC.

3. Power on the maintenance terminal. After the PC powers on, the Windows desktop is displayed. Refer to operating instructions shipped with the PC.

---

 **NOTE:** Procedures for changing network addresses using the HyperTerminal serial communication software are described in [step 4](#) through [step 13](#).

---

4. Select **Start > Programs > Accessories > Communications > HyperTerminal**. The Connection Description dialog box is displayed, ([Figure 7](#)).




**Figure 7** Connection Description dialog box

5. Enter **edge switch 2-24** in the Name field and click **OK**. The Connect To dialog box is displayed ([Figure 8](#)).



**Figure 8** Connect To dialog box

6. Ensure that the Connect using field displays COM1 or COM2 (depending on the serial communication port connection to the switch), and click **OK**. The Port Settings dialog box is displayed (Figure 9).



**Figure 9** Port Settings dialog box

7. Enter the Port Settings parameters as follows:

- Bits per second: **115200**
- Data bits: **8**
- Parity: **None**
- Stop bits: **1**
- Flow control: **Hardware**

When the parameters are set, click **OK**. The HyperTerminal window appears.

8. At the > prompt, enter the user-level password (the default is password). The password is case sensitive. The HyperTerminal window appears with a C> prompt at the top of the window (Figure 10).




Figure 10 HyperTerminal window

9. At the C> prompt, enter **ipconfig**. The HyperTerminal window is displayed with configuration information listed as follows:

- MAC Address
- IP Address (default is 10.1.1.10, factory preset is 10.1.1.10)
- Subnet Mask (default is 255.0.0.0).
- Gateway Address (default is 0.0.0.0)

Only the IP Address, Subnet Mask, and Gateway Address fields are configurable.

10. Change the IP address, subnet mask, and gateway address as directed by the customer's network administrator. To change switch network addresses, enter the following at the C> prompt:

```
ipconfig xxx.xxx.xxx.xxx yyy.yyy.yyy.yyy zzz.zzz.zzz.zzz
```

The IP address is always xxx.xxx.xxx.xxx, the subnet mask is always yyy.yyy.yyy.yyy, and the gateway address is always zzz.zzz.zzz.zzz, where the octets xxx, yyy, and zzz are decimals from zero through 255. If a network address is to remain unchanged, enter the current address in the respective field.

When the new network addresses are configured at the switch, the message Request completed OK appears at the bottom of the Edge Switch 2/24 — HyperTerminal window.

11. Select **File > Exit** to close the HyperTerminal window. A message box is displayed (Figure 11).




Figure 11 Disconnect Now dialog box

12. Click **Yes**. A message box is displayed (Figure 12).




Figure 12 Save Session dialog box

13. Click **No** to exit and close the HyperTerminal dialog box.

14. Power off the maintenance terminal:

- a. Select **Start > Shut Down**. The Shut Down Windows dialog box is displayed.
- b. Select **Shut down the Computer** and click **Yes** to power off the PC.

15. Disconnect the RS-232 null modem cable from the switch and the maintenance terminal. Replace the protective plate over the maintenance port.

## LAN-Connect the switch

Connect the switch to the Ethernet LAN segment or the HP-supplied Ethernet hub as follows:

1. Connect one end of the Ethernet patch cable (supplied with the switch) to the RJ-45 connector (labeled 10/100) on the left front of the chassis.
2. Connect the remaining end of the Ethernet cable to the LAN as follows:
  - a. If the switch is installed on a LAN segment, connect the cable to the LAN as directed by the customer's network administrator.
  - b. If the switch is installed on the HP-supplied Ethernet hub, connect the cable to any available port on the hub.
3. Perform one of the following steps:
  - If an HAFM appliance is delivered and available, go to "[Configure the HAFM appliance](#)" on page 39.
  - If an HAFM appliance is not available and the switch is managed through the EWS interface, attach the Ethernet LAN segment to an Internet connection and go to "[Using the Embedded Web Server](#)" on page 67.

# Configure the HAFM appliance

To run HAFM software, you must set up and configure the HAFM appliance.

Refer to the HAFM appliance installation guide for instructions on:

- Setting up the HAFM appliance.
- Connecting the HAFM appliance to the LAN.
- Configuring the network addressing for the HAFM appliance.
- Setting HAFM appliance date and time.
- Creating HAFM user names and passwords

## Record or verify HAFM appliance restore information

Configuration information must be recorded to restore the HAFM appliance in case of hard drive failure. The Windows operating system and the HAFM application must also be restored. Refer to the *HP StorageWorks Edge Switch 2/24 service manual* for instructions and configuration information.

## Enabling HAFM to manage the switch

To manage a new switch, it must be identified to the HAFM appliance. To identify the new switch:

1. At the HAFM application (Element manager or EWS main window), select the Setup option from the Discover menu. The Discover Setup dialog box is displayed (Figure 13).




Figure 13 Discover Setup dialog box

2. Click **Add**. The Domain Information dialog box is displayed with the IP Address page open by default (Figure 14).

**Figure 14** Domain Information dialog box (IP Address page)

3. Enter a switch description (for example, **edge-224**) in the Description field.
4. Enter the switch IP address (determined by the customer's network administrator) in the IP Address field.
5. Click **OK** to save the entered information, close the dialog box, and define the switch to the HAFM application.
6. Repeat [step 2](#) through [step 5](#) for each new switch.
7. Click **OK** to close the Discover Setup dialog box and return to the HAFM application.



## Verify communication between switch and HAFM appliance

Communication must be verified between the switch and the HAFM appliance Element Manager and EWS applications.

To verify switch-to-appliance communication:



1. At the HAFM application main window (physical map or product list), inspect the shape and color of the status symbol associated with the Edge Switch product icon. [Table 3](#) explains the symbols and associated operational states.

**Table 3** Switch operational states and symbols


Operational State	Symbol
Operational—Switch-to-appliance communication is established, the switch is operational, and no failures are indicated. Go to <a href="#">"Set switch date and time" on page 42</a> .	
Degraded—Switch-to-appliance communication is established, but the switch is operating in degraded mode and requires service. This condition is typical if a port or redundant FRU fails. Go to <a href="#">step 2</a> .	



**Table 3** Switch operational states and symbols

Operational State	Symbol
Failed—Switch-to appliance communication is established, but the switch failed and requires immediate service. Go to <a href="#">step 2</a> .	
Status Unknown—The switch status is unknown because of a network communication failure between the switch and HAFM appliance. Go to <a href="#">step 2</a> .	

2. Right-click the switch icon at the HAFM application's physical map. A pop-up menu appears.
3. Select the **Element Manager** option from the pop-up menu. When the Element Manager application opens, the last view (tab) accessed by a user opens by default. The example in [Figure 15](#) shows the Hardware View.



**Figure 15** Switch Hardware View page


4. Inspect switch status at the Hardware View page and perform one of the following steps:
  - a. If the switch displays operational (no FRU alert symbols and a green circle at the alert panel), go to ["Set switch date and time" on page 42](#).
  - b. If switch operation displays degraded or a switch failure is indicated (FRU alert symbols and a yellow triangle or red diamond at the alert panel), refer to the *HP StorageWorks Edge Switch 2/24 service manual* to isolate the problem.

## Set switch date and time

The Edge Switch 2/24 Element Manager log entries are stamped with the date and time received from the switch. To set the effective date and time for the switch:

1. At the Hardware View page for the selected switch, select **Configure > Date/Time**. The Configure Date and Time dialog box is displayed (Figure 16).

The switch date and time can be set manually, or set to be periodically updated by the HAFM application (the switch and HAFM application synchronize at least once daily).



**Figure 16** Configure Date and Time dialog box

## Set date and time manually

To set the switch date and time manually:

1. At the Configure Date and Time dialog box, click **Periodic Date/Time Synchronization** to deselect the option (no check mark in the box). The greyed out Date and Time fields activate.
2. Click the Date fields that require change, and type numbers in the following ranges:  
Month (MM): 1 through 12  
Day (DD): 1 through 31  
Year (YY): greater than 1980
3. Click the Time fields that require change, and type numbers in the following ranges:  
Hour (HH): 0 through 23  
Minute (MM): 0 through 59  
Second (SS): 0 through 59
4. Click **Activate** to set the switch date and time and close the Configure Date and Time dialog box.

## Periodically Synchronize date and time


To set the switch to periodically synchronize date and time with the *HAFM* application:

1. Click **Periodic Date/Time Synchronization** to select the option (check mark in the box). The Date and Time fields are greyed out and not selectable. Perform one of the following options:
  - Click **Activate** to enable synchronization and close the Configure Date and Time dialog box. The switch date and time synchronize with the HAFM application date and time at the next update period (at least once daily).
  - Click **Sync Now** to synchronize the switch and HAFM application immediately. The Date and Time Synced dialog box is displayed.
2. Click **OK** to synchronize the date and time and close the Date and Time Synced dialog box, then click **Activate** to enable synchronization and close the Configure Date and Time dialog box.

## Frequently used HAFM settings

This section summarizes the most common HAFM tasks, including:

---

 **NOTE:** For a complete reference on HAFM functionality, refer to the *HP StorageWorks HA-Fabric Manager user guide*.

---

- [Set the switch online](#), page 44
- [Set the switch offline](#), page 44
- [Configure switch identification](#), page 44
- [Configure switch operating parameters](#), page 45
- [Configure fabric operating parameters](#), page 48
- [Configure switch binding](#), page 50
- [Configure SNMP trap message recipients](#), page 52
- [Configure, enable, and test e-mail notification](#), page 53
- [Configure and enable Ethernet events](#), page 54
- [Configure call home event notification](#), page 54
- [Configure threshold alerts](#), page 54
- [Back up HAFM configuration data](#), page 60
- [Configure open systems management appliance](#), page 60
- [Configure feature key](#), page 61
- [Configure Open Trunking](#), page 61
- [Enable Embedded Web Server](#), page 61
- [Enable Telnet](#), page 61
- [Connect cables to Fibre Channel ports](#), page 61

## Set the switch online

When the switch is set online, an attached device can log into the switch if the port is not blocked. Attached devices can communicate with each other if they are configured in the same zone. Use these steps to set the switch online:

1. Open HAFM. The Products View page is displayed.
2. Double-click the appropriate switch icon. The Hardware View page for the selected switch is displayed.
3. Select **Maintenance > Set Online State**. If the switch is offline, the Set Online State dialog box is displayed, indicating the status is offline.
4. Click **Set Online**. A Warning dialog box is displayed, indicating status is online.
5. Click **OK**. The Status table displays *Online*.

## Set the switch offline

When the Edge Switch 2/24 is set offline, all ports are set offline. The switch transmits the offline sequence (OLS) to attached devices, and the devices cannot log in to the switch. Use these steps to set the switch offline:


1. Notify the customer that the switch is going offline.
2. Open HAFM. The Products View page is displayed.
3. Select the appropriate switch icon. The Hardware View page for the selected switch is displayed.
4. Select **Maintenance > Set Online State**. If the switch is online, the Set Online State dialog box is displayed, indicating the status is *Online*.
5. Click **Set Offline**. A Warning dialog box is displayed, indicating the switch will be set offline.
6. Click **OK**.

## Configure switch identification

Perform this procedure to configure the switch name, description, location, and contact person. The Name, Location, and Contact variables configured here correspond respectively to the SNMP variables `sysName`, `sysLocation`, and `sysContact`. These variables are used by SNMP management workstations when obtaining data from managed switches.

To configure the switch identification:

1. Select **Configure > Identification** tab. The Configure Identification dialog box is displayed, as shown in [Figure 17](#).



The image shows a 'Configure Identification' dialog box. It has a title bar at the top. Below the title bar, there are four text input fields labeled 'Name:', 'Description:', 'Location:', and 'Contact:'. The 'Name:' field has a 'Copy >' button next to it. At the bottom right of the dialog box, there are three buttons: 'Activate', 'Cancel', and 'Help'.

**Figure 17** Configure Identification dialog box

- a. Enter a switch name of 24 or fewer alphanumeric characters in the Name field. Each switch should be configured with a unique name.  
If the switch is installed on a public LAN, the name should reflect the switch's Ethernet network DNS host name. For example, if the DNS host name is hpes224.hp.com, then enter **hpes224**.
  - b. Enter a switch description of 255 or fewer alphanumeric characters in the Description field.
  - c. Enter the switch physical location (255 or fewer alphanumeric characters) in the Location field.
  - d. Enter the name of a contact person (255 or fewer alphanumeric characters) in the Contact field.
2. Click **Activate** to save the information. The message Your changes to the identification configuration have been successfully activated is displayed.

## Configure switch operating parameters

Use the procedures in this section to set parameters on the switch for fabric operation through the Configure Switch Parameters dialog box. These operating parameters are stored in NVRAM on the switch.

The switch must be offline to change Preferred Domain ID and other operating parameters.


1. Ensure that the switch is set offline. For instructions, see "[Set the switch offline](#)" on page 44.

---

△ **CAUTION:** Setting the switch offline terminates all Fibre Channel connections.


---

2. Select **Configure > Operating Parameters > Switch Parameters**. The **Configure Switch Parameters** dialog box is displayed ([Figure 18](#)).



**Figure 18** Configure Switch Parameters dialog box

---

 **NOTE:** Ordinarily, you do not need to change values in this dialog box from their defaults. The only exception is the Preferred Domain ID. Change this value if the switch will participate in a multiswitch fabric.

---

3. Use information in “[Switch parameters](#)” on page 46” which follows, to change settings as required for parameters in this dialog box.
4. After you change settings, click **Activate**.
5. Set the switch online. For instructions, see “[Set the switch online](#)” on page 44.

## Switch parameters

Configure the following parameters as required by your fabric.


### Domain ID

The domain identification is a value from 1 through 31 that provides a unique identification for the switch in a fabric. An Edge Switch cannot contain the same domain ID, as another switch or their E\_Ports will segment when they try to join.

In the Configure Switch Parameters dialog box, a field is provided to enter a preferred domain ID and a check box is provided to enable this ID as an insistent domain ID.

### Preferred

---

 **NOTE:** To change this value, you must first set the switch offline. For instructions, see “[Set the switch offline](#)” on page 44.

---

Use this field to set a unique domain ID for the switch. The default value is 1. Set a value between 1 and 31. When a switch comes online with a preferred ID, it requests an ID from the fabric’s principal switch (indicating its preferred value as part of the request). If the requested domain ID is not allocated to the fabric, the domain ID is assigned to the requesting switch. If the requested domain ID is already allocated, an unused domain ID is assigned. Note that you must set the switch offline before you can change to the preferred domain ID.

The preferred domain ID must be unique for each director and switch in a fabric. If two switches or directors have the same preferred domain ID, the E\_Ports segment, causing the fabric to segment.

For more information on domain ID, refer to the section on domain ID assignment for multiswitch fabrics in the *HP StorageWorks High Availability SAN planning guide*.

### Insistent

This option is not supported unless the SANtegrity feature is installed. Click the check box to remove or add a check mark. The default state is disabled (no check mark).

When a check mark is displayed, the domain ID configured in the Preferred Domain ID field will become the active domain identification when the fabric initializes. See the following notes:

- This option is required if High Availability Fabric Manager (HAFM) is enabled.
- If you enable Insistent Domain while the switch or director is online, the Preferred Domain ID will change to the current active domain ID if the IDs are different.


- 
- △ **CAUTION:** If a switch with a duplicate domain ID exists in the fabric, both switches' E\_Ports will segment when they try to join.
- 

### Rerouting delay

Placing a check mark in the check box to the left of the **Rerouting Delay** option enables rerouting delay. This option is only applicable if the configured switch is in a multiswitch fabric. The default state is enabled.

Enabling the rerouting delay ensures that frames are delivered in order through the fabric to their destination. If there is a change to the fabric topology that creates a new path (for example, a new switch is added to the fabric), frames may be routed over this new path if its hop count is less than a previous path with a minimum hop count. This may result in frames being delivered to a destination out of order since frames sent over the new, shorter path may arrive ahead of older frames still in route over the older path.

If rerouting delay is enabled, traffic ceases in the fabric for the time specified in the E\_D\_TOV field of the Configure Fabric Parameters dialog box. This delay allows frames sent on the old path to exit to their destination before new frames begin traversing the new path.

- 
-  **NOTE:** This option is required if you are using the HAFM appliance.
- 

### Domain RSCNs

Domain register for state change notifications (domain RSCNs) are sent between end devices in a fabric to provide additional connection information to host bus adapters (HBA) and storage devices. As an example, this information might be that a logical path has been broken because of a physical event, such as a fiber optic cable being disconnected from a port. Consult with your HBA and storage device vendor to determine if enabling Domain RSCNs will cause problems with your HBA or storage products. Note that this option is required if Enterprise Fabric Mode (optional SANtegrity binding feature) is enabled.

### Suppress RSCNs on zone set activations

Fabric format domain register for state change notifications (RSCNs) are sent to ports on the switch following any change to the fabric's active zone set. These changes include activating and deactivating the zone set, or enabling and disabling the default zone. When the Suppress RSCNs on Zone Set Activations check box is selected, fabric format RSCNs are not sent for zone changes to the attached devices on the switch. Click the check box to remove or add a checkmark.

This option is enabled (check box not selected) by default. In most cases this option should be enabled so that attached devices can receive notification of zoning changes in the fabric. However, some HBAs may log out, then log back into the fabric when they receive an RSCN, thereby disrupting Fibre Channel traffic. Consult with your HBA and storage device vendor to determine if disabling this option (and thereby enabling RSCN transmission) will cause problems with your HBA or storage products.

## Configure fabric operating parameters

Use procedures in this section to set parameters on the switch for fabric operation through the Configure Fabric Parameters dialog box. These operating parameters are stored in NV-RAM on the switch.

The switch must be offline to change parameters in this dialog box.


1. Ensure that the switch is set offline. For instructions, see ["Set the switch offline"](#) on page 44.

---

△ **CAUTION:** Setting the switch offline terminates all Fibre Channel connections.

---


2. At the Hardware View, select **Operating Parameters > Fabric Parameters** from the Element Manager window. The Configure Fabric Parameters dialog box is displayed ([Figure 19](#)).



The screenshot shows a dialog box titled 'Configure Fabric Parameters'. It has four input fields with labels: 'R\_A\_TOV:' with a value of '20' and '(tenths of a second)' in parentheses; 'E\_D\_TOV:' with a value of '4' and '(tenths of a second)' in parentheses; 'Switch Priority:' with a dropdown menu showing 'Default'; and 'Interop Mode:' with a dropdown menu showing 'Open Fabric 1.0'. At the bottom of the dialog are three buttons: 'Activate', 'Cancel', and 'Help'.

**Figure 19** Configure Fabric Parameters dialog box

---

 **NOTE:** Ordinarily, you do not need to change values in this dialog box from their defaults. The only exception is the Preferred Domain ID. Change this value if the switch will participate in a multiswitch fabric.

---

3. Use information under ["Fabric parameters"](#) on page 49 to change settings as required for parameters in this dialog box.
4. After you change settings, click the **Activate** button.
5. Back up the configuration data when you are finished configuring the switch.
6. Set the switch online. For instructions, see ["Set the switch online"](#) on page 44.




## Fabric parameters

Configure the following parameters as required by your fabric.

### R\_A\_TOV

Configure resource allocation time-out value (R\_A\_TOV) in tenth-of-a-second increments. This variable works with the error detect time-out value (E\_D\_TOV) variable to control the switch's behavior when an error condition occurs. Resources are allocated to a circuit when errors are detected and are not released for reuse until the time set by the R\_A\_TOV value expires. The default value is 100 tenths (10 seconds). Set a value between 10 tenths and 1200 tenths (1 through 120 seconds).

---


 **NOTE:** Set the same value for R\_A\_TOV on all directors and switches in a multiswitch fabric. If the value is not the same on all units, the fabric segments. Also, the value for R\_A\_TOV must be greater than the value configured for E\_D\_TOV.

---

### E\_D\_TOV

Adjust the E\_D\_TOV in tenth-of-a-second increments. An error condition occurs when an expected response is not received within the time limit set by this value. The default value is 20 tenths (2 seconds). Set a value between 2 tenths through 600 tenths (.2 through 60 seconds).

---

 **NOTE:** Set the same value for E\_D\_TOV on all switches and directors in a multiswitch fabric. If the value is not the same, the fabric segments. Also, the value for E\_D\_TOV must be less than the value configured for R\_A\_TOV.

---

## Switch priority

Setting this value determines the principal switch for the multiswitch fabric. Select **Principal** (highest priority), **Default**, or **Never Principal** (lowest priority) from the Switch Priority drop-down list.


Setting these priority values determines the principal switch selected for the multiswitch fabric. For example, if you have three switches in the fabric and set one as Principal, one as Default, and one as Never Principal, the unit set to Principal becomes the principal switch in the fabric.

If all switches are set to Principal or Default, the switch with the highest priority and the lowest WWN becomes the principal switch. Following are some examples of principal switch selection when switches have these settings:

- If you have three switches and set all to Default, the switch with the lowest WWN becomes the principal switch.
- If you have three switches and set two to Principal and one to Default, the switch with the Principal setting that has the lowest WWN becomes the principal switch.
- If you have three switches and set two to Default and one to Never Principal, the switch with the Default setting and the lowest WWN becomes the principal switch.

At least one switch in a multiswitch fabric needs to be set as Principal or Default. If all of the switches are set to Never Principal, all of the interswitch links (ISLs) will segment. If all but one switch is set to Never Principal and the switch that was principal goes offline, then all of the other ISLs will segment.

---

 **NOTE:** HP recommends that you leave the switch priority setting as Default. If you are considering setting this value to something other than default, refer to the section on principal switch selection for multiswitch fabrics in the *HP StorageWorks SAN High Availability planning guide* for details.

---

In, for example, the audit log, you may notice that the Principal setting maps to a number code of 1, Default maps to a number code of 254, and Never Principal maps to a number code of 255. The number codes of 2-253 are not currently in use.

### Interop Mode

Select one of the following options:

- **Homogeneous Fabric**—Select this mode if the fabric contains only HP directors and switches that are operating in Homogeneous Fabric mode.
- **Open Fabric 1.0**—Default. Select this mode if the fabric contains HP directors and switches, as well as other open-fabric compliant switches. Select this mode for managing heterogeneous fabrics.


## Configure switch binding

This feature is managed through the Switch Binding submenu options available on the Element Manager Configure menu. Using Switch Binding, you can specify devices and switches that can attach to director and switch ports. This provides security in environments that include a large number of devices by ensuring that only the intended set of devices attach to a switch or director. For complete procedures on configuring this optional feature, refer to *HP StorageWorks Edge Switch Element Manager user guide*.

The preferred path feature lets you specify and configure one or more ISL data paths between multiple directors or switches in a fabric. Each participating director or switch must be configured as part of a desired path. The following rules apply when configuring a preferred path:

- The switch domain ID must be set to *Insistent*. For instructions, refer to "[Configure switch operating parameters](#)" on page 45.
- Domain IDs range between 1 through 31.
- Source and exit port numbers are limited to the range of ports available on the switch (0 through 23).
- For each source port, only one path is defined to each destination domain ID.


---

 **NOTE:** Activating a preferred path can result in receipt of out-of-order frames if the preferred path differs from the current path, if input and output (I/O) is active from the source port, and if congestions is present on the current path.

---


To configure one or more preferred paths for the switch:

1. At the Hardware View, select **Configure > Preferred Path**. The Configure Preferred Paths dialog box is displayed (Figure 20).



**Figure 20** Configure Preferred Paths dialog box

2. Click **Add**. The Add Preferred Path dialog box is displayed (Figure 21).



**Figure 21** Add Preferred Path dialog box

3. At the Source Port field, type a value between 0 through 23. For this switch, the value uniquely identifies the starting port for the preferred path.
4. At the Exit Port field, type a value between 0 through 23. For this switch, the value uniquely identifies the exit port for the preferred path.
5. At the Destination Domain ID field, type a value between 1 through 31. This value uniquely identifies the destination director or switch in the path.
6. Click **OK** to close the Add Preferred Path dialog box and add the path to the list at the Configure Preferred Paths dialog box.
7. Repeat [step 2](#) through [step 6](#) to configure additional preferred paths.
8. At the Configure Preferred Paths dialog box, select (click) the **Enable Preferred Path** check box.
9. Click **Activate** to enable all configured preferred paths and close the dialog box.

# Configure SNMP trap message recipients

Perform this procedure to configure community names, write authorizations, and network addresses and for up to 12 SNMP trap message recipients on the HAFM appliance. A trap recipient is a management workstation that receives notification (through SNMP) if a switch event occurs.

To configure SNMP trap recipients:

1. At the Hardware View page for the selected switch, select **Configure > SNMP Agent**. The Configure SNMP Agent dialog box is displayed (Figure 22).

Community Name	Write Authorization	Trap Recipient	UDP Port Number
	<input type="checkbox"/>		
	<input type="checkbox"/>		
	<input type="checkbox"/>		
	<input type="checkbox"/>		
	<input type="checkbox"/>		
	<input type="checkbox"/>		

**Figure 22** Configure SNMP Agent dialog box


- a. For each trap recipient to be configured, enter a community name of 64 or fewer alphanumeric characters in the associated Community Name field. The community name is incorporated in SNMP trap messages to ensure against unauthorized viewing or use.
  - b. Click the check box in the **Write Authorization** column to enable or disable write authorization for the trap recipient (default is disabled). A check mark in the box indicates write authorization is enabled. When the feature is enabled, a management workstation user can change the HAFM appliance’s `sysContact`, `sysName`, and `sysLocation` SNMP variables.
  - c. Enter the IP address or DNS host name of the trap recipient (SNMP management workstation) in the associated Trap Recipient field. Use 32 or fewer alphanumeric characters. HP recommends that the IP address be used.
  - d. The default user datagram protocol (UDP) port number for trap recipients is 162. Enter a decimal port number in the associated UDP Port Number field to override the default.
2. To enable transmission of trap messages to configured SNMP management workstations, click **Enable Authentication Traps**. A check mark is displayed in the box when transmission is enabled (see Figure 22).
  3. Click **Activate** to save the information and close the dialog box.

## Configure, enable, and test e-mail notification

Perform this procedure to configure, enable, and test e-mail and simple mail transfer protocol (SMTP) addresses to receive notification of switch (and other product) events. Configure and test procedures are performed at the HAFM appliance. E-mail notification is enabled for each switch at the HAFM application.

To configure, enable, and test e-mail server addresses:

1. Minimize the Hardware View and return to the HAFM application.
2. At the HAFM application main window, select **Monitor > Event Notification > E-mail**. The E-mail Event Notification Setup dialog box is displayed (Figure 23).



**Figure 23** Configure E-Mail dialog box

3. To enable or disable e-mail notification, click the **Enable Email Event Notification** checkbox.
4. Enter the IP address or DNS host name of the SMTP server in the E-mail Server field. Use 64 or fewer alphanumeric characters. HP recommends that the IP address be used.
5. Enter the e-mail address to which e-mail replies should be sent in the Reply field.
6. At the Summary Interval field, enter the length of time the application should wait between notifications. Select seconds, minutes, or hours from the associated drop-down list.  
Notifications are combined into a single e-mail and sent at each interval setting. An interval setting of zero will cause notifications to be sent immediately.

---

**IMPORTANT:** Setting too short of an interval can cause the recipient's e-mail inbox to fill very quickly.


---

7. To send a test e-mail, enter the e-mail address to which the test e-mail should be sent in the Send to field, or click **Send to all users enabled for notification**.
8. Click the **Send Test E-mail** to test the e-mail server.  
A message stating whether or not the server was found is displayed. If the server was not found, verify that the server address was entered correctly and that the server is running.
9. click **User List** to specify which users will receive e-mail notification.  
The HAFM Server Users dialog box displays. Select the check box in the Email column for each user you want to receive e-mail notification.
10. Click **OK** to save the information and close the E-mail Event Notification Setup dialog box.

## Configure and enable Ethernet events

Perform this procedure to configure and enable Ethernet events. An Ethernet event is recorded (after a user-specified time interval) when the switch-to-HAFM appliance communication link drops. To configure and enable Ethernet events:

1. Minimize the Hardware View and return to the HAFM application.
2. At the HAFM or EWS main window, select the **Monitor > Ethernet Event**. The Configure Ethernet Events dialog box is displayed (Figure 24).



**Figure 24** Configure Ethernet Events dialog box

3. Click the **Enable Ethernet Event** check box. A check mark is displayed in the check box to indicate Ethernet events are enabled.
4. Enter a value from 10 through 120 minutes in the Ethernet Timeout field.
5. Click **OK** to close the dialog box.

## Configure call home event notification

Telephone numbers and other information for the call-home feature are configured through the Windows dial-up networking application. To learn more about configuring call-home features, refer to the *HP StorageWorks HA-Fabric Manager Appliance installation guide*.

## Configure threshold alerts

A threshold alert notifies users when the transmit (Tx) or receive (Rx) throughput reaches specified values for specific switch ports or port types, (E\_Ports or F\_Ports).

You are notified of a threshold alert in four ways:

- A yellow triangle that is displayed on the port in the Port Card View.
- A yellow triangle that is displayed on the port in the Hardware View.
- A yellow triangle that is displayed in the Alert column of the Port List View.
- A yellow triangle that is displayed by the Threshold Alerts field in the Port Properties dialog box.
- Detailed threshold alert data recorded in the Threshold Alert Log.

Use the Threshold Alerts option on the Configure menu to configure the following:

- Name for the alert.
- Type of threshold for the alert (Rx, Tx, or either).
- Active or inactive state of the alert.


- You can configure up to 16 alerts, and any number of alerts can be active at one time. Use the following procedures to create a new threshold alert, or to modify, activate, deactivate, or delete an alert.

1. At the Hardware View page, select **Configure** > **Threshold Alerts**. The Configure Threshold Alerts dialog box is displayed, as shown in [Figure 25](#).

Name	Type	State
Transmit Exceed	Transmit	Inactive

Edge Switch 2/24 installation guide 55

2. Click **New**. The New Threshold Alert dialog box is displayed, as shown in [Figure 26](#).




**Figure 26** New Threshold Alerts dialog box—first screen

3. Enter a name from one to 64 characters in length. All characters in the ISO Latin-1 character set, excluding control characters, are allowed.
4. Select one of the following from the Threshold Type drop-down list:
- **Transmit**—An alert will occur if the threshold set for transmit throughput is reached.
  - **Receive**—An alert will occur if the threshold set for receive throughput is reached
  - **Receive and Transmit**—An alert will occur if the threshold set for either receive or transmit throughput is reached.
5. Click **Next**. A new screen is displayed with additional parameters, as shown in [Figure 27](#). The name configured for the alert is displayed at the top of the screen.



**NOTE:** Click **Previous** if you need to return to the previous screen.



**Figure 27** New Threshold Alerts dialog box—second screen



6. Enter a percentage from **1** through **100** for % utilization. When throughput reaches this percentage of port capacity, a threshold alert will occur.
7. Enter the amount of cumulative minutes in which the % utilization should exist during the notification interval before an alert is generated. You can also select **At any time** if you want an alert to occur whenever the set % utilization is reached. The valid range is from 1 to the interval value set in [step 8](#).
8. Enter the interval in minutes in which throughput is measured and threshold notifications can occur. The valid range is 5 minutes to 70,560 minutes.
9. Click **Next**. A new screen is displayed for selecting ports for the alerts, as shown in [Figure 28](#).

Select port(s) to run threshold alert on:

☐ Port Type

☐ E Ports

☐ F Ports

☐ FL Ports

☒ Port List

☒ Port 0

☒ Port 1

☒ Port 2

☒ Port 3

☒ Port 4

Set All Ports

Clear All Ports


<< Previous   Next >>   Finish   Cancel   Help

**Figure 28** New Threshold Alerts dialog box—third screen

**10.** Select either **Port Type** or **Port List**.


- For **Port Type**, select either **E\_Ports** or **F\_Ports**. This will cause this alert to generate for all ports configured as E\_Ports or F\_Ports respectively.
- For **Port List**, you can select individual ports by clicking the check box by each port number or set all ports. Selecting **Set All Ports** places a check mark by each port number. Selecting **Clear All Ports** will clear the check marks by each port number.

11. Click **Next**. A final screen is displayed to provide a summary of your alert configuration, as shown in Figure 29.



**Figure 29** New Threshold Alerts dialog box—summary screen

12. Click **Finish**. The Configure Threshold Alerts dialog box is displayed listing the name, type, and state of the alert that you just configured.
13. At this point, the alert is not active. To activate the alert, select the alert you want to activate in the Configure Threshold Alerts table and click **Activate**. The alert is activated.



**Figure 30** Configure Threshold Alerts dialog box—alert activated

## Modify alerts

Use the following steps to modify an existing threshold alert configuration.

1. At the Hardware View page, select **Configure > Threshold Alerts**. The Configure Threshold Alerts dialog box is displayed.
2. Select the alert that you want to modify by clicking the alert information in the table. If the alert is active, an error message is displayed prompting you to deactivate the alert.  
If the alert is active, click **Deactivate**, then select the alert information in the table again.
3. Click **Modify**. An initial Modify Threshold Alert screen is displayed, which allows you to change the threshold type.
4. Select a threshold type from the Threshold Type Transmit drop-down list.

5. Click **Next** when you are done. A Modify Threshold screen is displayed, which allows you to change the % utilization, cumulative minutes for the threshold to occur before notification, and the time interval for measuring throughput and for alert notification.
6. Make appropriate changes, then click **Next** and make appropriate changes to the final Modify Threshold Alert screen. Perform either of the following steps:
  - If you need to change any parameters, click **Previous** or **Next** to display the desired Modify Threshold screen.
  - Click **Finish** when the Modify Threshold Alert summary screen displays with the your selected information.

## Activate or deactivate alerts

Use the following steps to activate or deactivate existing threshold alerts. In the active state, notifications are generated for the alert. In the inactive state, notifications do not occur.

1. At the Hardware View page, select **Configure > Threshold Alerts**. The Configure Threshold Alerts dialog box is displayed.  
The port's current state, inactive or active, is listed under the **State** column.
2. To change the state, select the alert by the alert information in the table.
3. If the alert is active, select **Deactivate** to change to the inactive state. If the alert is inactive, select **Activate** to change to the active state.

## Delete alerts

Use the following steps to delete existing threshold alerts.

1. At the Hardware View page, select **Configure > Threshold Alerts**. The Configure Threshold Alerts dialog box is displayed.
2. Select the alert that you want to delete by selecting the alert information in the table and click **Delete**. A message is displayed asking you to confirm the deletion.
3. Click **Yes**. The alert is removed from the dialog box.

## Configure SANtegrity authentication

Use this optional feature to configure authentication security settings. You configure these setting using the SANtegrity Authentication dialog box.




**NOTE:** You must have Administrator privileges to access the SANtegrity Authentication dialog box.

---

To access the SANtegrity Authentication dialog box:

From the Element Manager window, select **Configure > SANtegrity Authentication**. The SANtegrity Authentication dialog box is displayed (Figure 31).



**Figure 31** SANtegrity Authentication dialog box

This dialog box contains five tabs:

- **Users**—Allows you to setup users who access the switch from CLI and Web interfaces.
- **Software**—Allows you to setup software applications that communicate with the switch through API, as well as OSMS authentication.
- **Devices**—Allows you to set device-to-device authentication parameters. The Devices tab is preferred path PFE key enabled. If a proper PFE key is not provided, the Devices tab is not accessible. See [“Configure feature key”](#) on page 61 for more information.
- **IP Access Control**—Allows you to setup IP addresses that can manage the switch.
- **Radius Servers**—Allows you to set Radius server parameters that the switch uses to communicate the authentication information to the designated Radius servers.

For information about using each of these tabs, see the online Help.

## Back up HAFM configuration data

It is important to back up the HAFM configuration data. This data is used to restore the HAFM appliance. See the *HP StorageWorks Edge Switch 2/24 service manual* for instructions on backing up the HAFM configuration data.

Once the HAFM configuration data is backed up, go to [“Connect cables to Fibre Channel ports”](#) on page 61.

## Configure open systems management appliance

For complete procedures on configuring this optional feature, refer to *HP StorageWorks Edge Switch Element Manager user guide*.

## Configure feature key

For complete procedures on configuring this feature, refer to *HP StorageWorks Edge Switch Element Manager user guide*.

## Configure Open Trunking

This option is only available if the optional Open Trunking feature is installed. Choosing this option opens the Configure Open Trunking dialog box. For details on enabling Open Trunking and configuring such parameters as congestion thresholds for ports, event notification options, and low BB credit threshold, refer to *HP StorageWorks Edge Switch Element Manager User Guide*.

## Enable Embedded Web Server

Use the following steps to enable EWS:

1. At the Hardware View page, select **Configure > Enable Web Server**. Choosing **Enable Web Server** automatically places a check mark in the check box.
2. Select **Enable Web Server** again to remove the check mark and disable the EWS interface. When disabled, remote users cannot access the interface.

For detailed information on using EWS, see ["Using the Embedded Web Server"](#) on page 67.

## Enable Telnet

Use the following steps to enable Telnet:

1. At the Hardware View, select **Configure > Enable Telnet**. Choosing **Enable Telnet** automatically places a check mark in the check box.
2. Select **Enable Telnet** again to remove the check mark and disable telnet access. When disabled, remote users cannot access the Edge Switch through telnet.

## Connect cables to Fibre Channel ports

Perform this task to connect devices to the switch. To cable Fibre Channel ports:

1. Route single mode or multimode fiber optic cables (depending on the type of SFP pluggable optic transceivers installed) from customer-specified devices to ports at the front of the switch.
2. Connect device cables to small form factor pluggable (SFP) transceivers. Start with port 0 and continue sequentially to the left through port 23.
3. Perform one of the following:
  - a. If the switch is installed on a table or desk top, bundle and secure the Fibre Channel cables as directed by the customer.
  - b. If the switch is installed in a customer-supplied equipment rack, bundle Fibre Channel cables from the switch and other equipment (groups of 16 maximum), and secure them as directed by the customer.
4. Set the switch online.

## Connect the switch to a fabric

To provide Fibre Channel connectivity between public devices and fabric-attached devices, connect the switch to an expansion port (E\_Port) of an HP director or Edge Switch. The switch port to switch port connection is called an interswitch link (ISL). To fabric-attach the Edge Switch and create an ISL:

1. Ensure that the Edge Switch is defined to the HAFM application (defined while performing ["Enabling HAFM to manage the switch"](#) on page 39).
2. Ensure that the preferred domain ID for the Edge Switch is unique and does not conflict with the ID of another Edge Switch participating in the fabric. To change the domain ID, see ["Configure switch operating parameters"](#) on page 45.
3. Ensure that the R\_A\_TOV and E\_D\_TOV values for the Edge Switch are identical to the values for all edge switches participating in the fabric. To change the values, see ["Configure fabric operating parameters"](#) on page 48.
4. Route a multimode or single mode fiber optic cable (depending on the type of SFP transceiver installed) from a customer-specified E\_Port of the switch to the switch.
5. Connect the switch-attached fiber optic cable to the port SFP transceiver.
6. If the Edge Switch is managed by an attached HAFM appliance, go to [step 7](#). If the Edge Switch is managed by the Embedded Web Server interface:
  - a. Select **View** at the left side of the window. The View window opens with the **Switch** tab selected and displayed.
  - b. At the View window, click the **Port Properties** tab. The Port Properties page is displayed with **0** selected, and port information listed for port 0.
  - c. Select the port number of the port used to make this ISL connection.
  - d. Ensure that the Operational State field displays **Online** and the Reason field displays **N/A** or is blank. If an ISL segmentation or other problem is indicated, refer to the *HP StorageWorks Edge Switch 2/24 service manual* to isolate the problem. If no problems are indicated, installation tasks are complete.
7. At the HAFM appliance's Product View page, double-click the **Edge Switch** icon. The Hardware View page for the selected Edge Switch is displayed.

8. Double-click the port connector used to make this ISL connection to open the Port Properties dialog box (Figure 32).


Port Number	9
Port Name	
Type	G_Port
Operating Speed	Not Established
Port WWN	McDATA-200D08008860308C
Block Configuration	Unblocked
RX BB Credits Configured	5
Logged in IDs	0
LIN Alerts Configuration	On
FAN Configuration	On
Beaconing	Off
Link Incident	None
Operational State	No Light
Reason	
Threshold Alert	
Zoning Enforcement	N/A

Close Help

**Figure 32** Port Properties dialog box

9. Ensure that the Link Incident field displays **None** and the Reason field is blank. If an ISL segmentation or other problem is indicated, refer to the *HP StorageWorks Edge Switch 2/24 service manual* to isolate the problem. If no problems are indicated, installation tasks are complete.

---

 **NOTE:** If the Open Trunking feature is installed an additional field (Congested Threshold %) appears in the Port Properties dialog box. This field displays the active congested threshold percentage currently configured in the Configure Open Trunking dialog box.

---

## Unpack, inspect, and install the ethernet hub (optional)

The HAFM appliance and one or more edge switches connect through an Ethernet hub installed on a 10/100 Mbps LAN segment. One hub port is required to connect the HAFM appliance, and one hub port is required to connect each edge switch. A combination of up to 48 HP products can be configured and managed by a single HAFM appliance, therefore multiple hubs may be required to provide sufficient port connections. These hubs must be connected in accordance with the hub manufacturer's specifications. HP recommends using a star or hub-and-spoke topology when connecting multiple hubs. The HAFM appliance must be connected to the center hub, and there should never be more than two hubs between the HAFM appliance and any edge switch. Refer to the hub manufacturer's documentation for more detailed information.

For instructions to unpack and inspect one or more Ethernet hubs, and to install the hubs in a desktop or rack-mount configuration, refer to the appropriate Ethernet hub documentation.


# Using HAFM from a remote location

Use this section to install the HAFM client on a remote workstation.

## Remote workstation minimum requirements

The minimum requirements described in “[Minimum remote workstation requirements](#)” on page 19 must be met to install HAFM on a remote workstation.

---


 **NOTE:** For HAFM to function properly, compatible versions must be installed on both the client machines and the HAFM appliance.

---

## Install HAFM client on a remote workstation

Use these steps to install HAFM on a remote client:

1. Verify that the workstation and the Ethernet LAN segment (with the Edge Switch 2/24 attached) are connected through the Internet.
2. At the workstation, launch the browser application.
3. At the browser, enter the HAFM appliance IP address.
4. The HAFM splash screen is displayed with the following options, see [Figure 33](#).
  - a. **Install HAFM remote client application**—Select this option to install the application for your workstation platform.
  - b. **Download SNMP MIB files**—The Management Information Base (MIB) files are provided in standard ASN.1 syntax and may be installed into the MIB database of any SNMPv2-compliant Network Management Station.



**Figure 33** HAFM remote client install



5. To install the remote client application, scroll down to the information that pertains to your platform, and follow the instructions provided.
6. After you have downloaded the installer executable, the InstallAnywhere Wizard is displayed. Follow the instructions provided to continue the installation.

## Launch HAFM from the remote client

Use these steps to launch HAFM from a remote client:

1. Double-click the **HAFM** icon to launch HAFM. The HAFM Login screen is displayed.
2. Enter the user name and password.



**NOTE:** The default user name is *Administrator*. The default password is *password*. Both user name and password are case-sensitive.

---


3. Enter the IP address of the HAFM appliance, or select an HAFM appliance from the HAFM appliance drop-down list. The list includes HAFM appliances to which you have previously logged in.
4. Click **Login**. The HAFM appliance opens.



### 3 Using the Embedded Web Server

If an HAFM appliance is not available, or is not used to manage the switch, use the Embedded Web Server (EWS) interface to configure the Edge Switch 2/24. Selectively perform the following configuration tasks according to your installation requirements:

- [Configure switch ports](#), page 68
- [Configure switch and fabric parameters](#), page 71
- [Configure network information](#), page 74
- [Configure SNMP trap message recipients](#), page 76
- [Enable or disable the CLI](#), page 77
- [Configure user rights](#), page 78


 **NOTE:** This chapter describes the initial setup of the Edge Switch 2/24 using the EWS interface. For additional information on configuring more advanced features using EWS, see the online EWS help or the *HP StorageWorks Embedded Web Server user guide*.

### Accessing the Embedded Web Server

A PC platform with LAN access and standard web browser running Netscape Navigator 4.6 or later or Microsoft Internet Explorer 4.0 or later is required.

To open the Embedded Web Server interface:


1. Ensure that the browser-capable PC and the Ethernet LAN segment (with the switch attached) are connected.
2. At the PC, launch the browser application (Netscape Navigator or Internet Explorer).
3. At the browser, enter the IP address of the switch as the Internet uniform resource locator (URL). Use the default IP address of 10.1.1.10, the factory preset of 10.1.1.10, or the IP address configured while performing "[Configure network information](#)" on page 74. The Enter Network Password dialog box is displayed, as shown in [Figure 34](#).



**Figure 34** Enter Network Password dialog box


4. Enter the default user name and password.

---

 **NOTE:** The default user name is *Administrator* and the default password is *password*. The user name and password are case-sensitive.

---

5. Click **OK**. The Embedded Web Server interface opens with the View window displayed, as shown in Figure 35.




**Figure 35** Embedded Web Server interface—View window

## Configure switch ports

Perform the procedure in this section to configure names and operating characteristics for the switch ports.

To configure one or more ports:

1. Click **Configure** at the left side of the window. The **Configure** window opens with the **Ports** tab displayed (Figure 36).
  - a. For each port to be configured, type a port name of 24 alphanumeric characters or less in the associated Name field. The port name should identify the device to which the port is attached.
  - b. Click the check box in the **Blocked** column to block or unblock a port (default is unblocked). A check mark in the box indicates the port is blocked. Blocking a port prevents the attached device from communicating with the switch. A blocked port continuously transmits the offline sequence (OLS).



**Figure 36** Block or unblock a port from the Configure window


- c. Click the check box in the **FAN** column to enable or disable the fabric address notification (FAN) feature (default is enabled). A check mark in the box indicates FAN is enabled. When the feature is enabled, the port transmits FAN frames after loop initialization to verify that FC-AL devices are still logged in. HP recommends this option be enabled for ports configured for loop operation.
  - d. Select the port type from the Type drop-down list. Available selections are:
    - Generic mixed port (**GX\_Port**) - Use this selection to configure a port as a generic loop port (GL\_Port). This selection is available only if enabled through an optional feature key.
    - Fabric mixed port (**FX\_Port**) - Use this selection to configure a port as a fabric loop port (FL\_Port).
    - Generic port (**G\_Port**) - This selection is available only if enabled through an optional feature key.
    - Fabric port (**F\_Port**).
    - Expansion port (**E\_Port**) - This selection is available only if enabled through an optional feature key.
  - e. Select the port speed from the Speed drop-down list. Available selections are:
    - **Negotiate**—Auto-negotiate between 1.0625 and 2.125 gigabit per second (Gbps) operation. This is the default selection.
    - **1 Gb/sec**—1.0625 Gbps operation.
    - **2 Gb/sec**—2.125 Gbps operation.
2. Click **Activate** to save the information. The message Your changes to the Port configuration have been successfully activated is displayed.

## Configure Switch Identification

Perform this procedure to configure the switch name, description, location, and contact person for the HAFM application. The information is displayed in multiple dialog boxes throughout the application. In addition, the Name, Location, and Contact variables configured at the Configure Identification dialog box correspond respectively to the SNMP variables `sysName`, `sysLocation`, and `sysContact`. These variables are used by SNMP management workstations when obtaining data from managed switches.

To configure the switch identification:

1. At the Configure window, click the **Switch** tab. The Switch page is displayed with the Identification tab selected (Figure 37).




**Figure 37** Configure Switch Identification tab

- a. Enter a switch name of 24 or fewer alphanumeric characters in the Name field. Each switch should be configured with a unique name.  
If the switch is installed on a public LAN, the name should reflect the switch's Ethernet network DNS host name. For example, if the DNS host name is `hpes232.hp.com`, enter **hpes232**.
  - b. Enter a switch description (255 or fewer alphanumeric characters) in the Description field.
  - c. Enter the switch physical location (255 or fewer alphanumeric characters) in the Location field.
  - d. Enter the name of a contact person (255 or fewer alphanumeric characters) in the Contact field.
2. Click **Activate** to configure the switch identification and close the dialog box.

## Configure date and time

Perform this procedure to configure the effective date and time for the switch. To set the date and time:

1. Select **Configure** > **Switch** > **Date/Time**. The Switch page is displayed with the Date/Time tab selected (Figure 38).



**Figure 38** Switch page—Date/Time tab

- a. Click the Date fields that require change, and enter numbers in the following ranges:  
Month (MM): 1 through 12  
Day (DD): 1 through 31  
Year (YY): greater than 1980
  - b. Click the Time fields that require change, and enter numbers in the following ranges:  
Hour (HH): 0 through 23  
Minute (MM): 0 through 59  
Second (SS): 0 through 59
2. Click **Activate** to save the information. The message Your changes to the Date/Time configuration have been successfully activated is displayed.

## Configure switch and fabric parameters


Perform this procedure to configure the following switch and fabric operating parameters: Buffer-to-Buffer Credit (BB\_Credit), Error Detect Time Out Value (E\_D\_TOV), and Resource Allocation Time Out Value (R\_A\_TOV), preferred domain ID, and switch priority.

### Configure switch parameters

The switch must be set offline to configure operating parameters. To configure the parameters:

1. Set the switch offline as follows:
  - a. Select **Operations** > **Online State** to display the Online State tab.
  - b. Click **Set Offline**. The message Your changes have been successfully activated is displayed.
2. Click **Configure** at the left side of the panel. The Configure panel opens with the Ports page displayed.

3. Select **Switch** > **Parameters** to display the Operating Parameters tab (Figure 39).




**Figure 39** Switch page—Parameters tab

4. Set the switch parameters:
  - a. In the Preferred Domain ID field, enter a value between 1 and 31 (default is 1). The domain ID uniquely identifies each switch in a fabric.

All fabric-attached switches must have unique domain IDs. If the value is not unique, the E\_Port connection to the switch segments and the switch cannot communicate with the fabric.
  - b. Select **Enabled** or **Disabled** from the Insistent Domain ID drop-down list. The default state is disabled. This option is not supported unless the SANtegrity feature is installed.

If insistent domain is enabled, the domain ID configured in the Preferred Domain ID field will become the active domain identification when the fabric initializes.

---

 **NOTE:** If you enable Insistent Domain while the switch or director is online, the Preferred Domain ID will change to the current active domain ID if the IDs are different.

---

- c. Select **Enabled** or **Disabled** from the Rerouting Delay drop-down list. The default state is enabled.

If rerouting delay is enabled, traffic is delayed through a fabric by the specified E\_D\_TOV time. This delay ensures Fibre Channel frames are delivered to their destination in order, even if a change to the fabric topology creates a new (shorter) transmission path.
- d. Select **Enabled** or **Disabled** from the Domain RSCNs drop-down list. The default state is disabled.

Domain register for state change notifications (domain RSCNs) are sent between end devices in a fabric to provide additional connection information to host bus adapters (HBAs) and storage devices. As an example, this information might be that a logical path has been broken because of a physical event, such as a fiber optic cable being disconnected from a port. Consult with your HBA and storage device vendor to determine if enabling Domain RSCNs will cause problems with your HBA or storage products.




- e. Select **Enabled** or **Disabled** from the Suppress RSCNs on Zone set activations drop-down list. The default state is disabled.  
When the parameter is enabled, attached devices do not receive notification following any change to the fabric's active zone set.  
When the parameter is disabled, attached devices (registered through the fabric format domain register) do receive notification following any change to the fabric's active zone set.
5. Click **Activate** to save the information. The message Your changes to the Operating Parameters configuration have been successfully activated is displayed.
6. Set the switch online:
  - a. Select **Operations > Online State**. The Operations page is displayed with the Online State tab selected.
  - b. Click **Set Online**. The message Your changes have been successfully activated is displayed.

## Set fabric parameters

The switch must be set offline to configure fabric parameters. To configure the parameters:

1. Set the switch offline as follows:
  - a. At the View window, select **Operations** at the left side of the panel. The Operations panel opens with the Switch Beacon page displayed.
  - b. At the Operations panel, select the **Online State** tab, then click **Set Offline**. The message Your operations changes have been successfully activated is displayed.
2. At the View window, select **Configure** at the left side of the panel. The Configure panel opens with the Ports page displayed.
3. Click the **Switch** tab, then select the **Fabric Parameters** tab. The Switch page is displayed with the Fabric Parameters options (Figure 40).



**Figure 40** Switch page—Fabric parameters tab

4. Set the fabric parameters:
  - a. At the R\_A\_TOV field, enter a value between 10 through 1200 tenths of a second (one through 120 seconds). The default is 10 seconds (100 tenths).

All fabric-attached switches must be set to the same R\_A\_TOV. If the value is not compatible, the E\_Port connection to the switch segments and the switch cannot communicate with the fabric. In addition, the R\_A\_TOV must be greater than the E\_D\_TOV.
  - b. At the E\_D\_TOV field, enter a value between 2 through 600 tenths of a second (0.2 through 60 seconds). The default is 20 tenths of a second (2 seconds).

All fabric-attached switches must be set to the same E\_D\_TOV. If the value is not compatible, the E\_Port connection to the switch segments and the switch cannot communicate with the fabric. In addition, the E\_D\_TOV must be less than the R\_A\_TOV.
  - c. The switch priority value designates the fabric's principal switch. The principal switch controls the allocation and distribution of domain IDs for all fabric directors and switches (including itself). At the Switch Priority field, select **Principal**, **Never Principal**, or **Default** (the default setting is Default).
  - d. Select the Interop mode:
    - **McDATA Fabric 1.0**. (default). Select this mode if the fabric contains only M-Series switches that are operating in McDATA Fabric 1.0 mode.
    - **Open Fabric 1.0**. Select this mode if the fabric contains HP directors and switches, as well as other open fabric-compliant switches. Select this mode for managing heterogeneous fabrics.
5. Click **Activate** to save the information. The message *Your changes to the operating parameters configuration have been successfully activated is displayed*.
6. Set the switch online:
  - a. At the View window, select **Operations** at the left side of the panel. The Operations panel opens with the Switch Beacon page displayed.
  - b. At the Operations panel, click the **Online State** tab, then click **Set Online**. The message *Your operations changes have been successfully activated is displayed*.

## Configure network information

Verify that the type of LAN installation with the customer's network administrator. If one switch is installed on a dedicated LAN, network information (IP address, subnet mask, and gateway address) does not require change. Go to "[Configure switch ports](#)" on page 68.

If multiple switches are installed, or a public LAN segment is used, network information must be changed to conform to the customer's LAN addressing scheme. Perform one of the following:


- If network information was changed while performing "[Configure switch network information](#)" on page 34, this procedure is not required. Go to "[Configure SNMP trap message recipients](#)" on page 76.
- If network information was not changed, perform the following steps to change a switch IP address, subnet mask, or gateway address:

1. Select **Configure > Switch > Network** to display the Network tab (Figure 41).



**Figure 41** Switch page—Network tab

- a. At the IP Address field, enter the new value as specified by the network administrator [default (factory preset) is 10.1.1.10].
  - b. At the Subnet Mask field, enter the new value as specified by the network administrator (default is 255.0.0.0).
  - c. At the Gateway Address field, enter the new value as specified by the network administrator (default is 0.0.0.0).
2. Click **Activate** to save the information. The following message box is displayed (Figure 42).




**Figure 42** Network configuration changes activated

3. Update the address resolution protocol (ARP) table for the browser PC.
  - a. Select **File > Close** to close the EWS and browser applications. The Windows desktop appears.
  - b. Select **Start > Programs > Accessories > Command Prompt**. A disk operating system (DOS) window appears.

- c. Delete the switch's *old* IP address from the ARP table. At the command (C:\) prompt, enter `arp -d xxx.xxx.xxx.xxx`. The `xxx.xxx.xxx.xxx` is the old IP address for the switch.
- d. Click close (X) at the upper right corner of the DOS window to close the window or enter `exit` at the prompt to return to the Windows desktop.
4. At the PC, launch the browser application (Netscape Navigator or Internet Explorer).
5. At the browser, enter the switch's new IP address as the Internet URL. The Enter Network Password dialog box appears.
6. Enter the user name and password.

---

 **NOTE:** The default user name is *Administrator* and the default password is *password*. The user name and password are case-sensitive.

---


7. Click **OK**. The EWS interface opens with the View window displayed.

## Configure SNMP trap message recipients

Perform this procedure to configure community names, write authorizations, and network addresses and for up to six SNMP trap message recipients per Edge switch or director, or up to 12 SNMP trap message recipients per HAFM appliance. A trap recipient is a management workstation that receives notification (through SNMP) if a switch event occurs.

To configure SNMP trap recipients:

1. Select **Configure > Management** to display the SNMP tab (Figure 43).



Community Name	Write Authorization	Trap Recipient	UDP Port Number
public	<input type="checkbox"/>		162
public	<input type="checkbox"/>		162
public	<input type="checkbox"/>		162
ovsadm	<input checked="" type="checkbox"/>		
	<input type="checkbox"/>		
	<input type="checkbox"/>		

**Figure 43** Management page—SNMP tab


- a. Click the **Enable Authentication Traps** check box to enable or disable transmission of SNMP trap messages to configured recipients.

- b. For each trap recipient to be configured, enter a community name of 32 or fewer alphanumeric characters in the associated Community Name field. The community name is incorporated in SNMP trap messages to ensure against unauthorized viewing or use.
  - c. Click the check box in the **Write Authorization** column to enable or disable write authorization for the trap recipient (default is disabled). A check mark in the box indicates write authorization is enabled. When the feature is enabled, a management workstation user can change `sysContact`, `sysName`, and `sysLocation` SNMP variables.
  - d. Enter the IP address or DNS host name of the trap recipient (SNMP management workstation) in the associated Trap Recipient field. Use 64 or fewer alphanumeric characters. HP recommends that the IP address be used.
  - e. The default user datagram protocol (UDP) port number for trap recipients is 162. Enter a decimal port number in the associated UDP Port Number field to override the default.
2. Click **Activate** to save the information. The message Your changes to the SNMP configuration have been successfully activated is displayed.

## Enable or disable the CLI

Perform this procedure to toggle (enable or disable) the state of the switch's command line interface. To change the CLI state:

1. Select **Configure > Management > CLI** to display the CLI tab (Figure 44).




**Figure 44** Management page—CLI tab

2. Click **Enable CLI**, then click **Activate** to activate the CLI. The message Your changes to the CLI configuration have been successfully activated is displayed.


# Configure user rights

Perform this procedure to change the administrator-level and operator-level passwords used to access the EWS interface through the Enter Network Password dialog box.

 **NOTE:** If you want to create a user account, review the *Embedded Web Server User Guide* for more information. Before you create a new user, you should review information on the security features provided with SANtegrity and RADIUS Servers, including authentication for the various interfaces such as Web (HTTP), CLI, Serial Port, E Port, N Port, and OSMS.

To configure passwords:

1. Select **Configure > Security** to display the Authorize Users (Auth Users) tab [Figure 45](#).



Configure: Refresh 2 / 10 / 05 at 16:28:11

Ports Switch Management Zoning Security Performance

Auth Users Auth Settings Port Binding Switch Binding Fabric Binding >>

Interface: Web GO!

**New User Record**

Username	Password	Confirm Password	Role	Include CLI
			Administrator	<input type="checkbox"/>

Add User

**Current User Records**

Username	New Password	Confirm New Password	Role	CLI	Delete User
Administrator			Administrator	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Operator			Operator	<input checked="" type="checkbox"/>	<input type="checkbox"/>

Activate

**Figure 45** Security page–Auth User tab

2. Under Current User Records, enter the new password in the New Password column. Use 16 or fewer alphanumeric characters.
3. Enter the new password in the Confirm New Password column.
4. Select the appropriate role for the user from the Role drop-down list: **Adminstrator**, **Operator**, or **No Role**.
5. Click the **Include CLI** box to authorize the user to use the CLI.

Click **Activate** to activate save the information. The message Your changes to the Auth Users configuration have been successfully activated. Login may be required. is displayed.

## 4 Manage firmware versions


The Edge Switch 2/24 internal operating code is downloaded from the HAFM appliance and stored on a CTP card. Up to 32 versions can be stored on the HAFM appliance hard drive and made available for download to an Edge Switch. This chapter contains information on the following firmware management tasks:

- [Determine a switch firmware version](#), page 79
- [Add a firmware version](#), page 80
- [Modify a firmware version description](#), page 82
- [Delete a firmware version](#), page 82
- [Download a firmware version to a switch](#), page 83
- [Back up the configuration](#), page 85

### Determine a switch firmware version

To determine a switch firmware version from the management appliance (Element Manager application):

1. At the management appliance, open the SAN management application.
2. At the HAFM application's physical map, right-click the product icon representing the switch to be inspected for firmware version, then select **Element Manager** from the pop-up menu. The application opens.
3. Select **Maintenance > Firmware Library**. The Firmware Library dialog box is displayed ([Figure 46](#)).




**Figure 46** Firmware Library dialog box

4. The active firmware version is displayed at the lower left corner of the dialog box in `XX.YY.ZZ` format. The `XX` is the version level, `YY` is the release level, and `ZZ` is the patch level.
5. Click **Close**.

## Add a firmware version

The firmware version shipped with the Edge Switch is provided on the Edge Switch 2/24 documentation CD. Subsequent firmware versions to upgrade the Edge Switch are provided to customers through the HP web site.

---


 **NOTE:** When adding a firmware version, follow procedural information in the release notes that accompany the firmware version. This information supplements information provided in this general procedure.

---

Use these steps to add an edge switch firmware version to the library stored on the HAFM appliance hard drive:

1. Obtain the new firmware version from the HP web site:

---


 **NOTE:** The following path is subject to change.

---

- a. At the HAFM appliance or other personal computer (PC) with Internet access, open the HP web site. The uniform resource locator (URL) is <http://www.hp.com/country/us/eng/storage.html>.
  - b. Locate the **Networked storage** section of the Web page.
  - c. Under **Networked storage**, locate the **By type** subsection.
  - d. Click **SAN infrastructure**. The **SAN infrastructure** page appears.
  - e. Locate the **Fibre Channel Switches** section.
  - f. Go to the **M-Series Fabric** subsection and click **Edge Switch 2/24**. The **HP StorageWorks Edge Switch 2/24** page appears.
  - g. Locate the **Product information** section and click **Software, firmware & drivers**. The **specify operating system** page for your product appears.
  - h. Locate the **select operating system** section and click **Cross operating system (BIOS, Firmware, Diagnostics, etc.)**. The **download drivers and software** page for the selected product appears.
  - i. Locate the **Firmware** section and click **download** next to the firmware you want to download. The Windows Save As dialog box appears.  
Verify or correct the directory path specified in the Save in field and the file name specified in the File name field.
  - j. Click **Save**. The new firmware version is downloaded and saved to the HAFM appliance or PC hard drive.
2. At the HAFM application's physical map, right-click the product icon representing the switch for which a firmware version is to be added, then select **Element Manager** from the pop-up menu. The application opens.




3. Select **Maintenance > Firmware Library**. The Firmware Library dialog box is displayed (Figure 47).




**Figure 47** Firmware Library dialog box

4. Click **New**. The New Firmware Version dialog box is displayed (Figure 48).



**Figure 48** New Firmware Version dialog box

5. Select the desired firmware version file (downloaded in step 1) from the HAFM appliance backup drive, CD-ROM drive, or hard drive. Verify that the correct directory path and filename display in the File name field and click **Save**. The New Firmware Description dialog box is displayed (Figure 49).




**Figure 49** New Firmware Description dialog box

6. Enter a description (up to 24 characters in length) for the new firmware version and click **OK**. HP recommends that the description include the installation date and text that uniquely identifies the firmware version.
7. A Transfer Complete message box is displayed indicating the new firmware version is stored on the HAFM appliance hard drive. Click **Close** to close the message box.  
The new firmware version and associated description display in the Switch Firmware Library dialog box.
8. Click **Close**.
9. To send the firmware version to an Edge Switch, see "[Download a firmware version to a switch](#)" on page 83.

## Modify a firmware version description

Use these steps to modify the description of an Edge Switch firmware version in the library stored on the HAFM appliance hard drive:

1. At the HAFM appliance, open the HAFM application. The Products View page is displayed.
2. Double-click the icon representing the Edge Switch for which the firmware version description will be modified. The Hardware View page for the selected Edge Switch is displayed.
3. Select **Maintenance > Firmware Library**. The Switch Firmware Library dialog box is displayed, as shown in [Figure 46](#).
4. Select the firmware version to be modified and click **Modify**. The Modify Firmware Description dialog box is displayed, as shown in [Figure 50](#).



**Figure 50** Modify Firmware Description dialog box

5. Enter a modified description (up to 24 characters in length) for the firmware version and click **OK**. HP recommends that the description include the installation date and text that uniquely identifies the firmware version.
6. The new description for the firmware version is displayed in the Switch Firmware Library dialog box.
7. Click **Close**.

## Delete a firmware version

Use these steps to delete a firmware version from the library stored on the HAFM appliance hard drive:

1. At the HAFM appliance, open the HAFM application. The Products View page is displayed.
2. Double-click the icon representing the Edge Switch from which the firmware version will be deleted. The Hardware View page for the selected Edge Switch is displayed.
3. Select **Maintenance > Firmware Library**. The Switch Firmware Library dialog box is displayed, as shown in [Figure 46](#) on page 79.
4. Select the firmware version to be deleted and click **Delete**. A confirmation dialog box is displayed.
5. Click **OK**. The selected firmware version is deleted from the Switch Firmware Library dialog box.
6. Click **Close**.

## Download a firmware version to a switch

This procedure downloads a selected firmware version from the HAFM appliance library to an Edge Switch managed by the open instance of the Element Manager application. The procedure applies to an Edge switch with one CTP2 card, or a director with two (redundant) CTP2 cards. The process occurs concurrently without taking the Edge Switch offline or disrupting operation. The new firmware version takes effect when control is passed from the active to the backup CTP card. Although Edge Switch operation is not affected, name server, alias server, and login server functions are momentarily unavailable during CTP card switchover. Although traffic is not disrupted, the green port LEDs will flicker or blink during the IPL portion of this operation as control is passed to the other CTP card.



**NOTE:** When downloading a firmware version, follow procedural information in the release notes that accompany the firmware version. This information supplements information provided in this general procedure.


Use these steps to download a firmware version to an Edge Switch:

1. At the HAFM appliance, open the HAFM application. The Products View page is displayed.
2. Before downloading firmware version **XX.YY.ZZ** to an Edge Switch, Ensure that the required, compatible version of the HAFM application is running on the HAFM appliance. Refer to the release notes that shipped with HAFM.
  - a. Select **Help > About**. The About dialog box is displayed and lists the HAFM application version. Click **OK** to close the dialog box.
  - b. If required, install the correct version of the HAFM application.
3. Double-click the icon representing the Edge Switch to which the firmware version will be downloaded. The Hardware View page for the selected Edge Switch is displayed.
4. As a precaution to preserve Edge Switch configuration information, complete the data collection procedure as follows:
  - a. At the HAFM appliance, open the HAFM application. The Products View page is displayed.
  - b. Double-click the icon representing the Edge Switch for which the configuration file is to be backed up. The Hardware View page for the selected Edge Switch is displayed.
  - c. Select **Maintenance > Backup & Restore Configuration**. The Backup and Restore Configuration dialog box is displayed.
  - d. Click **Backup**. When the backup process finishes, the Backup Complete dialog box is displayed.
  - e. Click **OK** to close the dialog box and return to the Hardware View page.
5. Select **Maintenance > Firmware Library**. The Switch Firmware Library dialog box is displayed, as shown in [Figure 46](#) on page 79.

6. Select the firmware version to be downloaded and click **Send**. The send function verifies existence of certain Edge Switch conditions before the download process begins. If an error occurs, a message is displayed indicating the problem must be fixed before firmware is downloaded. Conditions that terminate the process include:

- A redundant CTP card failure.
- The firmware version is being installed to the Edge Switch by another user.
- The Edge Switch-to-HAFM appliance link is down.

If a problem occurs and a corresponding message is displayed, refer to the *HP StorageWorks Edge Switch 2/24 service manual* for specific information on isolating the problem. If no error occurs, the Send Firmware confirmation box is displayed, as shown in [Figure 51](#).



**Figure 51** Send Firmware Warning dialog box

7. Click **Yes**. The Send Firmware dialog box is displayed.

As the download begins, a `Writing data to FLASH` message is displayed at the top of the dialog box, followed by a `Sending Files` message. This message remains as a progress bar travels across the dialog box to show percent completion of the download. The bar progresses to 50% when the last file is transmitted to the first CTP card. The bar remains at the 50% point until the Edge Switch performs an Initial Program Load (IPL) (indicated by an `IPLing` message).

During the IPL, the Edge Switch-to-HAFM appliance link drops momentarily and the following events occur at the Element Manager:

- As the network connection drops, the Edge Switch Status table turns yellow, the Status field displays `No Link`, and the State field displays a reason message.
- The alert panel at the bottom of the navigation control panel displays a grey square, indicating Edge Switch status is unknown.
- Illustrated FRUs in the Hardware View page are removed, and then displayed again as the connection is re-established.


After the IPL, a `Synchronizing CTPs` message is displayed. This message remains as files are transmitted to the second CTP card and the progress bar travels across the dialog box to 100%. When the download reaches 100%, a `Send firmware complete` message is displayed.

8. Click **Close** to close the dialog box.
9. Click **Close** again to complete the operation.

## Back up the configuration


Use these steps to back up the configuration file on the HAFM appliance.

1. At the HAFM appliance, open the HAFM application. The Products View page is displayed.
2. At the SAN management application's physical map, right-click the product icon representing the switch for which a configuration file is to be backed up, then select **Element Manager** from the pop-up menu. The application opens.
3. Select **Maintenance > Backup & Restore Configuration**. The Backup and Restore Configuration dialog box is displayed (Figure 52).



**Figure 52** Backup and Restore Configuration dialog box

4. Click **Backup**. An Information dialog box is displayed, indicating the backup operation was initiated (Figure 53).



**Figure 53** Information dialog box

5. Click **OK** to complete the backup operation and close the dialog box.



---

## A Regulatory compliance and safety

This appendix covers the following topics:

- [Federal Communications Commission notice](#), page 87
- [Regulatory compliance identification numbers](#), page 89
- [Laser device](#), page 89
- [Canadian notice \(avis Canadien\)](#), page 90
- [European Union notice](#), page 90
- [BSMI notice](#), page 91
- [Japanese notice](#), page 91
- [Korean notices](#), page 92
- [Battery replacement notice](#), page 92
- [Taiwan battery recycling notice](#), page 93
- [Power cords](#), page 93
- [Japanese power cord notice](#), page 93
- [Electrostatic discharge](#), page 93

### Regulatory compliance

#### Federal Communications Commission notice

Part 15 of the Federal Communications Commission (FCC) Rules and Regulations has established Radio Frequency (RF) emission limits to provide an interference-free radio frequency spectrum. Many electronic devices, including computers, generate RF energy incidental to their intended function and are, therefore, covered by these rules. These rules place computers and related peripheral devices into two classes, A and B, depending upon their intended installation. Class A devices are those that may reasonably be expected to be installed in a business or commercial environment. Class B devices are those that may reasonably be expected to be installed in a residential environment (i.e., personal computers). The FCC requires devices in both classes to bear a label indicating the interference potential of the device as well as additional operating instructions for the user.

The rating label on the device shows which class (A or B) the equipment falls into. Class B devices have an FCC logo or FCC ID on the label. Class A devices do not have an FCC logo or FCC ID on the label. Once the class of the device is determined, refer to the following corresponding statement.

## Class A equipment

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at personal expense.

## Class B equipment

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit that is different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or television technician for help.

## Declaration of conformity for products marked with the FCC logo, United States only

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For questions regarding your product, visit <http://www.hp.com>.

For questions regarding this FCC declaration, contact us by mail or telephone:

- Hewlett-Packard Company  
P.O. Box 692000, Mailstop 510101  
Houston, Texas 77269-2000
- 1-281-514-3333

To identify this product, refer to the part, Regulatory Model Number, or product number found on the product.

## Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Hewlett-Packard Company may void the user's authority to operate the equipment.



## Cables

Connections to this device must be made with shielded cables with metallic RFI/EMI connector hoods in order to maintain compliance with FCC Rules and Regulations.

## Regulatory compliance identification numbers

For the purpose of regulatory compliance certifications and identification, your product has been assigned a unique Regulatory Model Number. The RMN can be found on the product nameplate label, along with all required approval markings and information. When requesting compliance information for this product, always refer to this RMN. The Regulatory Model Number should not be confused with the marketing name or model number of the product.

## Laser device

All HP systems equipped with a laser device comply with safety standards, including International Electrotechnical Commission (IEC) 825. With specific regard to the laser, the equipment complies with laser product performance standards set by government agencies as a Class 1 laser product. The product does not emit hazardous light.

## Laser safety warning

---

 **WARNING!** To reduce the risk of exposure to hazardous radiation:

- Do not try to open the laser device enclosure. There are no user-serviceable components inside.
  - Do not operate controls, make adjustments, or perform procedures to the laser device other than those specified herein.
  - Allow only HP authorized service technicians to repair the laser device.
- 

## Certification and classification information

This product contains a laser internal to the fiber optic (FO) transceiver for connection to the Fibre Channel communications port.

In the USA, the FO transceiver is certified as a Class 1 laser product conforming to the requirements contained in the Department of Health and Human Services (DHHS) regulation 21 CFR, Subchapter J. A label on the plastic FO transceiver housing indicates the certification.

Outside the USA, the FO transceiver is certified as a Class 1 laser product conforming to the requirements contained in IEC 825-1:1993 and EN 60825-1:1994, including Amendment 1:1996 and Amendment 2:2001.

## Laser product label

The optional label in [Figure 54](#) or equivalent may be located on the surface of the HP supplied laser device.



This optional label indicates that the product is classified as a CLASS 1 LASER PRODUCT. This label may appear on the laser device installed in your product.

**Figure 54** Class 1 laser product label

## International notices and statements

### Canadian notice (avis Canadien)

#### Class A equipment

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

#### Class B equipment

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

### European Union notice

Products bearing the CE marking comply with the EMC Directive (89/336/EEC) and the Low Voltage Directive (73/23/EEC) issued by the Commission of the European Community and if this product has telecommunication functionality, the R&TTE Directive (1999/5/EC).

Compliance with these directives implies conformity to the following European Norms (in parentheses are the equivalent international standards and regulations):

- EN55022 (CISPR 22) - Electromagnetic Interference
- EN55024 (IEC61000-4-2, IEC61000-4-3, IEC61000-4-4, IEC61000-4-5, IEC61000-4-6, IEC61000-4-8, IEC61000-4-11) - Electromagnetic Immunity
- Power Quality:
  - EN61000-3-2 (IEC61000-3-2) - Power Line Harmonics
  - EN61000-3-3 (IEC61000-3-3) - Power Line Flicker

- EN60950 (IEC60950) - Product Safety
- Also approved under UL 60950/CSA C22.2 No. 60950-00, Safety of Information Technology Equipment.

## BSMI notice

### 警告使用者:

這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。

## Japanese notice

ご使用になっている装置にVCCIマークが付いていましたら、次の説明文をお読み下さい。

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。

取扱説明書に従って正しい取り扱いをして下さい。

VCCIマークが付いていない場合には、次の点にご注意下さい。

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

## Korean notices

### A급 기기 (업무용 정보통신기기)

이 기기는 업무용으로 전자파적합등록을 한 기기이오니 판매자 또는 사용자는 이 점을 주의하시기 바라며, 만약 잘못판매 또는 구입하였을 때에는 가정용으로 교환하시기 바랍니다.

### B급 기기 (가정용 정보통신기기)

이 기기는 가정용으로 전자파적합등록을 한 기기로서 주거지역에서는 물론 모든 지역에서 사용할 수 있습니다.


## Safety

### Battery replacement notice

Your computer is equipped with a lithium manganese dioxide, a vanadium pentoxide, or an alkaline internal battery or battery pack. There is a danger of explosion and risk of personal injury if the battery is incorrectly replaced or mistreated. Replacement is to be done by an HP authorized service provider using the HP spare part designated for this product. For more information about battery replacement or proper disposal, contact an HP authorized reseller or HP authorized service provider.

**⚠ WARNING!** Your computer contains an internal lithium manganese dioxide, a vanadium pentoxide, or an alkaline battery pack. There is risk of fire and burns if the battery pack is not properly handled. To reduce the risk of personal injury:

- Do not attempt to recharge the battery.
- Do not expose to temperatures higher than 60°C.
- Do not disassemble, crush, puncture, short external contacts, or dispose of in fire or water.
- Replace only with the HP spare part designated for this product.



Batteries, battery packs, and accumulators should not be disposed of together with the general household waste. To forward them to recycling or proper disposal, please use the public collection system or return them to HP, an authorized HP Partner, or their agents.

For more information about battery replacement or proper disposal, contact an HP authorized reseller or service provider.

## Taiwan battery recycling notice



廢電池請回收


The Taiwan EPA requires dry battery manufacturing or importing firms in accordance with Article 15 of the Waste Disposal Act to indicate the recovery marks on the batteries used in sales, giveaway or promotion. Contact a qualified Taiwanese recycler for proper battery disposal.

## Power cords

The power cord set must meet the requirements for use in the country where the product was purchased. If the product is to be used in another country, purchase a power cord that is approved for use in that country.

The power cord must be rated for the product and for the voltage and current marked on the product electrical ratings label. The voltage and current rating of the cord should be greater than the voltage and current rating marked on the product. In addition, the diameter of the wire must be a minimum of 1.00 mm<sup>2</sup> or 18 AWG, and the length of the cord must be between 1.8 m (6 ft) and 3.6 m (12 ft). If you have questions about the type of power cord to use, contact an HP authorized service provider.

---

 **NOTE:** Route power cords so that they will not be walked on and cannot be pinched by items placed upon or against them. Pay particular attention to the plug, electrical outlet, and the point where the cords exit from the product.

---

## Japanese power cord notice

製品には、同梱された電源コードをお使い下さい。  
同梱された電源コードは、他の製品では使用出来ません。

## Electrostatic discharge

To prevent damage to the system, be aware of the precautions you need to follow when setting up the system or handling parts. A discharge of static electricity from a finger or other conductor may damage system boards or other static-sensitive devices. This type of damage may reduce the life expectancy of the device.

## Preventing electrostatic damage

To prevent electrostatic damage, observe the following precautions:

- Avoid hand contact by transporting and storing products in static-safe containers.
- Keep electrostatic-sensitive parts in their containers until they arrive at static-free workstations.
- Place parts on a grounded surface before removing them from their containers.
- Avoid touching pins, leads, or circuitry.
- Always be properly grounded when touching a static-sensitive component or assembly (see "[Grounding methods](#)" on page 94).


## Grounding methods

There are several methods for grounding. Use one or more of the following methods when handling or installing electrostatic-sensitive parts:

- Use a wrist strap connected by a ground cord to a grounded workstation or computer chassis. Wrist straps are flexible straps with a minimum of 1 megohm ( $\pm 10$  percent) resistance in the ground cords. To provide proper ground, wear the strap snug against the skin.
- Use heel straps, toe straps, or boot straps at standing workstations. Wear the straps on both feet when standing on conductive floors or dissipating floor mats.
- Use conductive field service tools.
- Use a portable field service kit with a folding static-dissipating work mat.

If you do not have any of the suggested equipment for proper grounding, have an HP authorized reseller install the part.

---

 **NOTE:** For more information on static electricity, or assistance with product installation, contact your HP authorized reseller.

---

# B Technical specifications

This appendix contains the following information:

- [Factory defaults](#), page 95
- [Physical dimensions](#), page 97
- [Environmental specifications](#), page 97
- [Power requirements](#), page 98
- [Operating tolerances](#), page 98
- [Laser information](#), page 99

## Factory defaults

[Table 4](#) lists the defaults for the passwords and IP, subnet, and gateway addresses.

**Table 4** Factory-set defaults

Item	Default
User name	Administrator
Customer password	password
Maintenance password	level-2
IP address	10.1.1.10
Subnet mask	255.0.0.0
Gateway address	0.0.0.0

[Table 5](#) provides the Edge Switch factor default values for Reset Configuration option.

**Table 5** Switch factory-default values for reset configuration option

Configuration	Description	Default
Identification	Switch Name	NULL string
	Switch Description	"Fibre Channel Switch"
	Switch Contact	"End User Contact (please configure)"
	Switch Location	"End User Contact (please configure)"

**Table 5** Switch factory-default values for reset configuration option (continued)

Configuration	Description	Default
Ports	Port Names	NULL strings
	Port Blocked States	Unblocked
	FAN	Enabled
	LIN Alerts	Enabled
	Ports enabled	8
Switch Addressing	IP Address	10.1.1.10
	Subnet Mask	255.0.0.0
	Gateway Address	0.0.0.0
	MAC Address	PROM value
Operating Mode	Must select one of two modes: McData 1.0 or Open Fabric 1.0. The recommended mode is Open Fabric 1.0.	Open Fabric 1.0 mode
Operating Parameters	Preferred Domain ID	1
	R_A_TOV	10 seconds (100 tenths)
	E_D_TOV	2 seconds (20 tenths)
	Switch Priority	Default
	Switch Speed	2 Gb/sec
	Rerouting Delay	Enabled
SNMP	SNMP Communities	"public" — 5 NULL strings
	SNMP Write Authorizations	Read only per community
	Trap Recipient IP Addressees	0 for each
	UDP Port	162
	SNMP Authorization Trap State	disabled
Management appliance	Active Equal Saved State	Disabled
	Remote Offline Control State	Disabled



**Table 5** Switch factory-default values for reset configuration option (continued)

Configuration	Description	Default
Zoning	Number of Zone Members	0
	Number of Zones	0
	Number of Zone Sets	0
	Zone Names	None
	Zone Sets Names	None
	Zone Members	None
	Default Zone State	Disabled
	Active Zone Set State	Disabled
	Active Zone Set Name	NULL string

## Physical dimensions

**Table 6** lists Edge Switch 2/24 dimensions.

**Table 6** Dimensions

Dimension	Size
Height	4.3 cm (1.7 in)
Width	43.4 cm (17.1 in)
Depth	48.3 cm (19.0 in)
Weight	7.7 kg (17 lb)
Shipping Weight	18.1 kg (40 lb)

## Environmental specifications

**Table 7** lists environmental ranges for shipping, storing, and operating the HP StorageWorks Edge Switch 2/24.

**Table 7** Environmental specifications

Specification	Shipping	Storage	Operating
Weight	18.1 kg (40 lb)	7.7 kg (17 lb)	7.7 kg (17 lb)
Temperature	-40° F to 140° F (-40° C to 60° C)	34° F to 140° F (1° C to 60° C)	40°F to 104°F (4°C to 40 °C)
Humidity	5% to 100%	5% to 80%	8% to 80%

**Table 7** Environmental specifications (continued)

Specification	Shipping	Storage	Operating
Maximum wet-bulb temperature	84° F (29° C)	84°F (29°C)	81°F (27°C)
Altitude	40,000 ft (12,192 m)	40,000 ft (12,192 m)	10,000 ft (3,048 m)

## Power requirements

Table 8 lists Edge Switch 2/24 power requirements.

**Table 8** Power requirements

Specification	Value
Input voltage	90 to 264 VAC
Input frequency	47 to 63 Hz

## Operating tolerances

Table 9 lists heating and cooling specifications, shock tolerances, vibration, acoustical noise, and inclination.

**Table 9** Operating tolerances

Specification	Value
Heat dissipation	49 watts (167 BTU/hr)
Cooling airflow clearances	Right and left sides: 1.3 cm (0.5 inches) Front and rear: 7.6 cm (3.0 in) Top and bottom: No clearance required
Shock and vibration tolerance	60 Gs for 10 milliseconds without nonrecoverable errors
Acoustical noise	70 dB "A" scale
Inclination	10° maximum

## Laser information

Three configurations of cards with fixed optics will be provided for each of the connector types: four extended long-wave ports, four long-wave ports, and four short-wave ports.

**Table 10** Laser specifications—2 Gb

Part Number	Transceivers on UPM Card	Wave Length	Media/ Distance	Standard
300836-B21 Long wave: 35 Km	4 Extended Long wave	1310 nm	9/125 $\mu$ m Single-mode: 1 m–35 Km	100-SM-LL-L
300835-B21 Long wave: 10 Km	4 Long wave	1310 nm	9/125 $\mu$ m Single-mode: 1 m–10 Km	100-SM-LL-L
300834-B21 Short wave	4 Short wave	850 nm	50/125 $\mu$ m Multimode: 2 m–500 m  62.5/125 $\mu$ m Multimode: 1 m–200 m	100-M5-SN-I



# Index

## A

- accumulators 92
- active zone set state, default value 97
- addresses, default values 96
- alkaline battery warning 92
- audience 9
- authorized reseller, HP 11
- Avis Canadien, regulatory compliance notice 90

## B

- backing up edge switch configuration file 85
- batteries
  - recycling or disposal 92
  - replacement
    - notice 92
    - warning 92
  - Taiwan EPA recycling and disposal 93
- boot straps, using 94
- brackets
  - and rails 30
  - mounting 31
- BSMI, regulatory compliance notice 91

## C

- cables
  - FCC compliance statement 89
  - shielded 89
- Canada, regulatory compliance notice 90
- certification and classification information, laser 89
- Class A equipment, Canadian compliance statement 90
- Class B equipment, Canadian compliance statement 90
- command line interface (CLI) 20, 77
- configuration data, backing up 60
- configure menu
  - enable EWS 61
  - enable telnet 61
  - features 61

- configuring
  - e-mail notification 53
  - Ethernet events 54
  - fabric operating parameters 48
  - feature keys 61
  - management appliance 60
  - SNMP trap message recipients 52, 76
  - switch identification 70
  - switch parameters 45
- connecting switches to a fabric 62
- conventions
  - document 10
  - text symbols 10, 32
- cooling fan, description 17
- cord. See power cord
- current rating 93

## D

- declaration of conformity 88
- defaults
  - factory 95
  - operating parameters 96
  - reset configuration 95
  - switch priority setting 50
- diagnostics 24
- disposal, battery 92
- disposal, Taiwan EPA battery 93
- dissipating floor mats 94
- document
  - conventions 10
  - related documentation 9
- domain ID
  - insistent 46
  - preferred 46
- domain RSCNs 47
- downloading firmware 83

## E

- e\_d\_tov 49
  - default value 96
  - fabric segmentation 49
  - less than r\_a\_tov 49
  - multiswitch fabrics 49
  - rerouting delay 47
- E\_Ports
  - description 13
  - segmentation, preferred domain ID 46
- electrostatic damage prevention 93
- electrostatic discharge. See ESD
- Element Manager, description 18
- e-mail notification, configuring 53
- embedded web server. See EWS
- enabling
  - EWS 61
  - telnet 61
- error detection 20
- ESD (electrostatic discharge)
  - obtaining additional information 94
  - precautions 93
  - prevention measures 93
  - storing products 93
  - transporting products 93
  - types of damage from 93
- Ethernet
  - events, configure at HAFM appliance 54
  - events, enable at HAFM appliance 54
  - hub, unpacking, inspecting, and installing 63
- European Union, regulatory compliance notice 90
- EWS
  - configuring
    - date and time 71
    - network information 74
    - SNMP trap message recipients 76
    - switch ports 68
    - user rights 78
  - defined 18
  - enabling 61

## F

- F\_Port, description 13
- fabric parameters
  - e\_d\_tov 49
  - interop mode 50
  - r\_a\_tov 49
  - switch priority 49
- fabric segmentation
  - e\_d\_tov 49
  - preferred domain ID 46
- fabric, connecting switches to 62
- factory defaults 95
- FCC (Federal Communications Commission)
  - Class A Equipment, compliance notice 88
  - Class B Equipment, compliance notice 88
  - declaration of conformity 88
  - modifications 88
  - notice 87
- Federal Communications Commission. See FCC
- Fibre Channel
  - addresses 46
  - ports 16
- firmware
  - adding version 80
  - deleting version 82
  - determining version 79
  - downloading 83
  - modifying description 82
  - release notes 80
- FL\_Port, description 13
- floor mats, dissipating 94
- frames, routing of 47
- front panel features 14
- FRUs
  - power supplies 17
  - SFP transceivers 16

## G

- gateway address
  - configuring 34
  - default 95
- German noise declaration 92

- ground strap specifications 94
- grounding
  - methods 94
  - straps, wearing 94
  - suggested equipment for 94

## H

### HAFM

- configuring switch 39
- description 18
- recording and verifying restoration information 39
- remote location 64
- remote location requirements 64
- setting the switch offline 44
- setting the switch online 44

HAFM appliance. See HAFM

hardware, mounting 30

heel straps, using 94

help, obtaining 11, 12

High Availability-Fabric Manager See HAFM

homogeneous fabric, interop mode 50

hop counts 47

### HP

- address for
  - FCC questions 88
- authorized reseller 11
- series number 89
- storage web site 12
- Subscriber's choice web site 11
- technical support 11
- telephone number
  - FCC questions 88

## I

- identification, default values 95
- IEC EMC, worldwide regulatory compliance notice 90
- Initial Machine Load (IML) button 16
- insistent domain ID 46
- installation tasks
  - backing-up configuration data 60
  - cabling Fibre Channel ports 61
  - configuring
    - network addresses 34
    - switch to the HAFM application 39

- LAN-connecting the switch 38
- options 27
- recording and verifying HAFM appliance restoration information 39
- setting switch date and time 42
- setting up the HAFM appliance 39
- unpacking and inspecting
  - switch 28
- unpacking, inspecting, and installing
  - Ethernet hub 63
- verify installation requirements 27

interop mode 50

- homogeneous fabric 50
- open fabric 1.0 50

interswitch link, description 13

IP address

- configuring 34
- default 95
- default value 96

## J

### Japan

- regulatory compliance notice 91

## K

- kits, optional 24
- Korean, regulatory compliance notice 92

## L

- label, laser 90

### LAN

- connecting the switch 38
- connector 15

### laser

- international certification and classification information 89
- product label 90
- radiation, warning 89
- regulatory compliance notice 89

### LEDs

- port 16
- PWR LED 15
- System Error LED 15

- LIN alerts, default values 96

- lithium battery 92

## M

- MAC addresses
  - default 96
  - defined 34
- maintenance port 18
- management appliance
  - default values 96
  - open systems 60
- managing the switch 18
- mode, interop 50
- mounting hardware 30
- multiswitch fabric
  - defined 23
  - e\_d\_tov 49
  - principal switch 49
  - rerouting delay 47

## N

- network addresses, configuring 34
- network information, configuring from EWS 74
- noise declaration, German 92
- notebook PC 18
- NV-RAM 45, 48

## O

- online state, setting 44
- open fabric 1.0, interop mode 50
- open systems management appliance 60
- operating parameters, default values 96
- optional kits 24

## P

- parts
  - proper handling 93
  - storing 93
  - transporting 93
- password, default 95
- personal computer, HAFM 18
- port blocked states, default value 96
- ports
  - cabling 61
  - default values 96
  - Fibre Channel 16
  - LEDs 16
  - UDP, default value 96

- power
  - requirements 98
  - supplies 17
- power cord
  - compliance notice 93
  - current rating 93
  - replacement 93
  - set 93
  - voltage rating 93
- preferred domain ID 46
  - default value 96
- preventing electrostatic damage 93
- principal switch, determining 49
- priority, default value 96
- product manager
  - configuring switch identification 44

## R

- r\_a\_tov
  - default value 96
  - fabric parameters 49
  - greater than e\_d\_tov 49
- rack stability, warning 11
- rack types 29
- rails and brackets 30
- rails, mounting 31
- rear panel features 17
- recycling, battery 92
- recycling, Taiwan EPA battery 93
- regulatory compliance
  - information number 89
  - notices 87
    - BSMI 91
    - Canada 90
    - Class A 88
    - Class B 88
    - European Union 90
    - HP series number 89
    - IEC EMC statement, worldwide 90
    - Japan 91
    - Korean 92
    - lasers 89
    - modifications 88
    - shielded cables 89
- related documentation 9
- remote offline control states, default value 96



- replacing a power cord 93
- reporting 20
- rerouting delay, default value 47
- reset configuration defaults 95
- RFI/EMI connector hoods 89
- routing delay, default value 96

## S

- SANtegrity Binding features 50
- series number, regulatory compliance 89
- serviceability 20
- setting, online state 44
- SFP transceivers 16
  - longwave 16
  - shortwave 16
- slide rails, mounting 31
- SNMP
  - authorization trap states, default value 96
  - communities, default value 96
  - configuring trap message recipients, EWS 76
  - configuring trap recipients 52
  - default values 96
  - trap messages 76
  - write authorizations, default value 96
- software, diagnostic features 24
- speeds, default value 96
- static
  - electricity 93
- static-dissipating work mat 94
- static-safe containers
  - storing products 93
  - transporting products 93
- static-sensitive devices 93
- straps, ground
  - boot 94
  - heel 94
  - toe 94
- subnet mask
  - configuring 34
  - default 95
- Subscriber's choice, HP 11
- suppress RSCNs on zone set activations 47
- switch
  - binding 50
  - connecting to a fabric 62
  - connectors and indicators 14
  - default speed value 96

- firmware version 79
- identification, configuring 70
- installing in cabinet 33
- LAN connecting 38
- LEDs 15
- maintenance port 18
- management 18
  - CLI 20
  - EWS 18
  - HAFM 18
- multiswitch fabric 23
- network addresses 34
- power supplies 17
- principal, determining 49
- priority 49
- priority setting 50
- setting date and time 42
- SFP transceivers 16
- unpacking and inspecting 28
- switch parameters
  - domain RSCNs 47
  - insistent domain ID 46
  - NV-RAM storage 45, 48
  - preferred domain ID 46
  - rerouting delay 47
  - suppress RSCNs on zone set activations 47
- symbols in text 10, 32
- system
  - preventing electrostatic discharge to 93

## T

- Taiwan EPA battery recycling and disposal 93
- technical support, HP 11
- telephone numbers
  - FCC questions 88
- telnet, enabling 61
- text symbols 10, 32
- toe straps, using 94
- tools required 31
- tools, conductive type 94
- trap recipient IP addresses, default value 96

## U

- UDP port, default value 96
- user rights, configuring, EWS 78

## V

- versions, firmware
  - deleting 82
  - determining 79
  - modifying description 82
- voltage compliance rating 93

## W

- warning
  - rack stability 11
- warnings
  - alkaline batteries 92
  - battery replacement 92
  - lasers, radiation 89
- web sites
  - HP storage 12
  - HP Subscriber's choice 11
- work mat, static-dissipating 94
- wrist straps
  - specifications 94
  - using 94
- WWN, principal switch 49

## Z

- zone sets
  - default value 97
  - defined 23
- zones
  - members, default value 97
  - number of, default value 97
  - set state, default value 97
  - states, default value 97
- zoning
  - default values 97
  - defined 23